GE
Digital Energy

D20MX

Processor



Hardware User's Manual

994-0140
Version 1.00 Revision 2

imagination at work

General

Copyright Notice

© 2012, General Electric Company. All rights reserved.

The information contained in this online publication is the exclusive property of General Electric Company, except as otherwise indicated. You may view, copy and print documents and graphics incorporated in this online publication (the "Documents") subject to the following: (1) the Documents may be used solely for personal, informational, non-commercial purposes; (2) the Documents may not be modified or altered in any way; and (3) General Electric Company withholds permission for making the Documents or any portion thereof accessible via the internet. Except as expressly provided herein, you may not use, copy, print, display, reproduce, publish, license, post, transmit or distribute the Documents in whole or in part without the prior written permission of General Electric Company.

The information contained in this online publication is proprietary and subject to change without notice. The software described in this online publication is supplied under license and may be used or copied only in accordance with the terms of such license.

Trademark Notices

GE and are trademarks and service marks of General Electric Company.

* Trademarks of General Electric Company.

ERNI is a registered trademark of ERNI Elektroapparate GMBH. Hyperterminal is a registered trademark of Hilgraeve, Tera Term is a registered trademark of T. Teranishi, Incorporated. IEC is a registered trademark of Commission Electrotechnique Internationale. IEEE is a registered trademark of the Institute of Electrical and Electronics Engineers, Inc. Internet Explorer, Microsoft, and Windows are registered trademarks of Microsoft Corporation. JAVA and J2SE are registered trademarks of Sun Microsystems, Inc. Maxell is a registered trademark of Hitachi Maxell, Ltd. MiniSQL is a trademark of Hughes Technologies. Modbus is a registered trademark of Schneider Automation Inc. Panduit is a registered trademark of Panduit Corp. Saft is a registered trademark of SAFT société anonyme. SEL is a registered trademark of Schweitzer Engineering Laboratories, Inc. Silicon Systems is a registered trademark of Silicon Systems, Inc. Sonnenschein is a registered trademark of Deutsche Exide GMBH. Tadiran is a registered trademark of Tadiran Israel Electronics Industries Ltd. Toshiba is a registered trademark of Kabushiki Kaisha Toshiba, doing business as Toshiba Corporation. VESA is registered trademark of Video Electronics Standards Association Corporation.

Other company or product names mentioned in this document may be trademarks or registered trademarks of their respective companies.

This printed manual is recyclable.
Please return for recycling where facilities exist.

D20MX Processor

Table of contents

ABOUT THIS DOCUMENT

Purpose 7
Intended audience 7
Additional documentation 7
How to use this manual 8
Document conventions 8
Safety words and definitions 9

PRODUCT SUPPORT

Search technical support 11
Contact customer support 11
Product returns 12
Upgrade your D20MX processor firmware 12

BEFORE YOU START

Safety precautions 13
- Warning symbols 14

Regulatory compliance information 14
- CE Mark compliance 14
- Export control classification number 15

Product overview 15
- Product design 15
- D20MX Processor 15
- Security 16
- D20MX applications 16
- Firmware/FPGA versions 17
- D20 chassis 18
- Power supply 20
- Modems 21
- Peripherals 22

Ordering guide 23
D20MX upgrade kits 24
Product specifications 25
Storage recommendations 27
- Storage conditions 27

INSTALLING THE D20MX

D20 chassis layouts 29
Installation steps 31
Retrofitting the D20MX in an existing D20 33
Required tools and materials 35
Grounding the D20MX 36
Unpacking the D20MX 36
- Package contents 36

Connecting the power supply 37

CONNECTING TO DEVICES AND NETWORKS

Cabling overview 39
- D20MX front panel connectors 39
- General cabling requirements 40

Serial 41
D.20 Link 41
Twisted-pair Ethernet (for 526-3001 only) 42
Fiber optic Ethernet (for 526-3003 and 526-3005LF only) 43
LAN redundancy 44
IP addresses 44
RS-232 47
D20 system redundancy 47
- Failover sequence 49
- Required components 49
- RS-232 switch panel operation 50
- Redundancy wiring diagrams 50

POWERING-UP AND TESTING

Required for testing 53
- Accessing WESMAINT II+ using a terminal 54
- Terminal Emulation 54
- SHELL 54

Power up and test steps 54
Set up a PC to act as a WESMAINTII+ terminal 55
Power up the D20MX 55
Automatic on-line start-up test 55
- Code and configuration files 56
- Further testing 56

Test for redundancy 56
Check that fail-over is functioning correctly 57
Check that switch-over is functioning correctly 57
Verify either hardware or software switch-over 58

CONFIGURING THE SOFTWARE

Introduction to the D20MX software 59
D20MX user accounts 59
- Default user 60
- Recovery mode users 60

Download image files to the D20MX 61
- When to download 61
- Prerequisites for image download 61
- Download software over a serial connection 62
- Download software over a network connection 64

SGConfig firmware options 65
Update to the SAN0001 firmware option 66
Transfer D20/D200 configurations to the D20MX 68
Transferring a D20 configuration to the D20MX 69
Transferring a D200 configuration to the D20MX 74
Updating D20/D200 configurations to use the D20MX firmware definition with ConfigPro 75
Updating a D20 configuration to use the D20MX firmware definition with ConfigPro 76
Updating a D200 configuration to use the D20MX firmware definition with ConfigPro .. 78

USING THE D20MX
Front panel LEDs 81
Operational status LEDs 81
LAN port status LEDs 82
Fiber optic port status LEDs 82

SERVICING THE D20MX
Performing periodic inspection 83
Removing the D20MX processor module 83

DEFAULT ROLE-BASED ACCESS CONTROL MODEL
Configured roles in the D20MX 85

STANDARDS & PROTECTION
Compliance standards 91

LIST OF ACRONYMS
Acronym Definitions 95

Modification Record 103

D20MX Processor

About this Document

Purpose

This manual provides information about installing, setting up, using and maintaining your D20MX™ Processor. This manual does not provide any procedures for configuring the software of the D20MX.

Intended audience

This manual is intended for use by field technicians and maintenance personnel who are responsible for the installation, wiring and maintenance of SCADA equipment. This manual assumes that the user is experienced in:

- Electrical utility applications
- Electrical wiring and safety procedures
- Related other manufacturers' products, such as protective relays and communications equipment

Additional documentation

For further information about the D20MX, refer to the following documents.

- *SGConfig Online Help*
- D20/D200 Installation and Operation Guide, 994-0078
- Application Configuration Guides and User Guides (available on the D20MX Documentation CD)

How to use this manual

This manual describes how to install the D20MX and get it up and running for the first time.

Procedures are provided for all component options available for the D20MX. The components included in your D20MX depend on what was ordered for your substation application.

The software-related procedures in this manual are based on using a computer running Windows® XP. Some steps and dialog boxes may vary slightly if you are using another version of Windows.

Document conventions

The following typographic conventions are used throughout this manual:

Bold face is used for:

- Names of software program menus, editors, and dialog boxes; also for the names of menu commands, keyboard keys, icons and desktop shortcuts, and buttons and fields in editors and dialog boxes
- Names of hardware components
- User input that must be typed exactly

Italic face is used for:

- Emphasis
- Cross-references to sections, figures and tables within this manual and for titles of other documents
- File and directory names; examples of directory paths are generally given in the Windows format
- Placeholders for user input that is specific to the user. May also include angle brackets around the placeholder if the placeholder is already in italic text. For example, c:\<*product*>\product.def
- References to a parameter or field value shown

Safety words and definitions

Before attempting to install or use the device, review all safety indicators in this document to help prevent injury, equipment damage or downtime.

The following safety and equipment symbols are used in this document:

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

Indicates practices that are not related to personal injury.

D20MX Processor

Product Support

If you need help with any aspect of your GE Digital Energy product, you have a few options.

Search technical support

The GE Digital Energy Web site provides fast access to technical information, such as manuals, release notes and knowledge base topics at:

http://www.gedigitalenergy.com

Contact customer support

The GE Digital Energy Customer Service Center is open 24 hours a day, seven days a week for you to talk directly to a GE representative.

In the U.S. and Canada, call toll-free: 1 800-547-8629

International customers, please call: + 1 905-927-7070

Or e-mail to ge4service@ge.com

Have the following information ready to give to Customer Service:

- Ship to address (the address that the product is to be returned to)
- Bill to address (the address that the invoice is to be sent to)
- Contact name
- Contact phone number
- Contact fax number
- Contact e-mail address
- Product number / serial number
- Description of problem

The Customer Service centre will provide you with a case number for your reference.

Product returns

A Return Merchandise Authorization (RMA) number must accompany all equipment being returned for repair, servicing, or for any other reason. Before you return a product, please contact GE Digital Energy to obtain an RMA number and instructions for return shipments.

You will be sent the RMA number and RMA documents via fax or e-mail. Once you receive the RMA documents, attach them to the outside of the shipping package and ship to GE.

NOTE

Product returns will not be accepted unless accompanied by the Return Merchandise Authorization number.

Upgrade your D20MX processor firmware

The firmware of your D20MX Processor can be upgraded to provide the latest functionality and improvements. Visit the customer support web site at http://www.gedigitalenergy.com to download the upgrade software and instruction guide.

D20MX Processor

Chapter 1: Before You Start

The new D20MX processor card is a pin-for-pin compatible replacement for all generations of the D20 SBC, providing the latest revisions of common D20 applications and performance enhancements to support NERC-compliant Cyber security.

Before you begin installing and using the D20MX, review the information in this chapter, including the following topics:

- Safety precautions
- Regulatory compliance information
- Product overview
- Product specifications
- Storage recommendations

Read and thoroughly understand this manual before installing and operating the unit. Save these instructions for later use and reference.

WARNING! Failure to observe the instructions in this manual may result in serious injury or death.

Safety precautions

Follow all safety precautions and instructions in this manual.

Only qualified personnel should work on the D20MX. Maintenance personnel should be familiar with the technology and the hazards associated with electrical equipment.

- *Never* work alone.
- Before performing visual inspections, tests, or maintenance on this equipment, isolate or disconnect all hazardous live circuits and sources of electric power. Assume that all circuits are live until they have been completely de-energized, tested, and tagged. Pay particular attention to the design of the power system. Consider all sources of power, including the possibility of back feed.
- Turn off all power supplying the equipment in which the D20MX is to be installed before installing and wiring the D20MX.
- Operate only from the power source specified on the installed power supply module.
- Beware of potential hazards and wear personal protective equipment.

- The successful operation of this equipment depends upon proper handling, installation, and operation. Neglecting fundamental installation requirements may lead to personal injury as well as damage to electrical equipment or other property.
- All AC voltage terminals are protected from accidental contact by a mechanical safety shield.
- All electronic components within the D20MX are susceptible to damage from electrostatic discharge. To prevent damage when handling this product use approved static control procedures.
- Hazardous voltages can cause shock, burns or death. To prevent exposure to hazardous voltages, disconnect and lock out all power sources before servicing and removing components.
- If the D20MX is used in a manner not specified in this manual, the protection provided by the equipment may be impaired.
- Changes or modifications made to the unit not authorized by GE Digital Energy could void the warranty.

Warning symbols

Table 1 explains the meaning of warning symbols that may appear on the D20MX.

Table 1: Warning symbols

Symbol	Description
	The relevant circuit is direct current.
	The relevant circuit is alternating current.
	Caution: Refer to the documentation for important operation and maintenance instructions. Failure to take or avoid specified actions could result in loss of data or physical damage.
	Warning: Dangerous voltage constituting risk of electric shock is present within the unit. Failure to take or avoid specified actions could result in physical harm to the user.
	Earth/Ground Terminal
	Protective Ground Terminal
	Caution: Hot Surface

Regulatory compliance information

CE Mark compliance

The D20MX is rated as CISPR 11 Group 1 Class "A" equipment.

To meet essential safety requirements of the LV Directive 2006/95/EC, the D20 chassis must be installed in a secondary cabinet if an operating voltage on any of the terminals is equal to or higher than 50 VAC or 75 VDC. Proper wiring practices and applicable local safety standards defining protection against electrical shock must be followed at all times.

NOTE

To provide higher EMC immunity and maintain CE Mark compliance, the serial cables used for permanent RS-232 and RS-485 connections must comply with the following requirements:

- Cables must be shielded
- D type connector covers must provide EMC shielding (e.g., metallized plastic or die cast metal covers) for permanently connected RS-232 cables

NOTICE

Class "A" equipment is intended for use in an industrial environment. The equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause interference to other devices in the vicinity. If this equipment does cause interference with other devices, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving device
- Increase the separation between the equipment
- Connect the equipment into an outlet on a circuit different from that to which the other device(s) is connected
- Consult the manufacturer or field service technician for help

Export control classification number

The Export Control Classification Number (ECCN) of the D20MX Processor is 4A994.

Product overview

The D20 is a standalone remote terminal unit (RTU). It consists of a D20MX processor board, power supply, optional termination panels, and optional communications equipment in a 3U tall, 19-inch wide chassis. These components, combined with software applications running on the D20MX, form the D20 RTU System.

The D20 acts as a data concentrator and central processor. Field data gathered through the peripheral modules and external Intelligent Electronic Devices (IEDs) are stored in the system database and can be accessed by the application programs loaded on the D20.

Product design

The D20 design has horizontally mounted processor boards, with multiple boards in some versions.

Peripheral I/O boards operate independently of the main chassis and D20MX processor board. This means that you can use a D20 without direct connection to peripheral boards so that it acts as a master data concentrator to other RTUs. You can also hot-swap the peripherals without powering down the main processor. For information on peripheral modules, see the *D20/D200 Installation and Operations Guide* (part number 994-0078); see section: *Connections and Configuration*.

D20MX Processor

The D20MX is a single board computer built around a 667 MHz embedded PowerQUICC II Pro processor. The D20MX permits the D20 to be NERC CIPS compliant and introduces compliance to IEC standards; refer to *Appendix A, Standards & Protection* for the complete listing.

The D20MX can be retrofitted into either a D20 3U single-node VME chassis or D20 3U non-VME chassis. In a single-node VME chassis, this one processor module replaces the previous D20 M, M++, ME, and MEII CPU cards.

Due to aging printed circuit board assembly and mechanical constraints, only certain chassis from 2002 and onward can be used with a D20MX. This comprises the following chassis:

- D20 VME chassis 500-0280 Release 08 or higher,
- D20 Non-VME chassis 500-0305 Release 18 or higher

A solid partition between the Main processor bay and accessory bay prevents access to the harness from the fiber card to D20MX card (only applicable to the 526-3005LF fiber card version).

Security

The D20MX provides many new security improvements over its predecessors. To take advantage of these improvements, refer to the WESMAINT II+ for the D20MX Configuration Guide (B014-1NCG) for details on configuration of these security features of the D20MX.

D20MX applications

Table 2 lists the automation applications used on the D20MX. Notice that the application versions are different in the SAN0001 and SAN0002 columns (for example, see application ID B021N).

Table 2: D20MX applications

Application ID	Application Name	Description	Version	
			SAN0001	SAN0002
A026-1	Communication Watchdog	Reports on the state of communications between the RTU and a remote device.	321	321
A027	SOE Logger DTA	SOE Logger DTA configuration.	832	832
A030	Accumulator Freeze	Detects system status point changes and system accumulator point freezes.	300	300
A033-5	TEJAS V DPA	TEJAS V DPA configuration.	211	211
A035	Analog Reference	Analog reference check DTA.	211	211
A036N	ProLogic Executor	ProLogic Executor DTA	421	421
A059	Modbus DCA	Modbus Data Collection Application	911	911
A068	Modbus DPA	Modbus DPA Configuration	311	311
A088-0	SM DTA	Substation Maintenance DTA configuration	203	203
A113	PSR DCA	Programmable Synchrocheck Relay (PSR) DCA configuration	301	301
A118	Failover DTA	Failover data-translation application (DTA) configuration.	103	103
A123-0	NGC General DTA	NGC General DTA configuration.	111	111
A184-0	General Alarm DTA	Takes several alarms and groups them together under one General Alarm.	120	120
B003	D.20 Peripheral Link	D.20 peripheral interface.	751	751
B008-1	System Point Database	Maintains the database of system points in the RTU.	310	310
B009	Mailbox DTA	Mailbox system point conversion application.	400	310
B012N	IRIG-B	IRIG-B universal time coordination	201	201

Application ID	Application Name	Description	Version	
			SAN0001	SAN0002
B013	DNP V3.00 Data Link	Distributed network protocol (DNP) V3.00 data link configuration.	560	560
B014-1N	WESMAINT II+	RTU maintenance facility.	600	600
B015	Bridgeman	Bridgeman configuration.	530	530
B021N	DNP V3.00 DPA	Distributed Network Protocol (DNP) V3.00 DPA Configuration.	988	912
B023	DNP V3.00 DCA	Distributed Network Protocol (DNP) V3.00 DCA Configuration.	754	754
B034	Redundant Monitor	Redundant monitor configuration.	203	203
B045-0	D20AC WESMAINT II+ Display Screens	Provides D20AC WESMAINT II+ displays.	101	101
B052-0N	DNP Internet Data Link	DNP V3.00 Data Link over Internet.	351	351
B071-0	WESMAINT File Upload	Uploads files via the WESMAINT port as S records or using ZMODEM.	200	200
B100-0	Internet Protocol Stack	Internet Protocol Stack Configuration	141	141
B152-0N	IP Redundancy Monitor	Provides health and active pseudo DI points for LAN Ports.	100	100
B153-0	Password Synchronization Manager	Synchronizes passwords to Standby CCU	100	100
S032	D20S Peripheral Board (supports B003)	D20S Peripheral Board Code	303	303
S033	D20A Peripheral Board (supports B003)	D20A Peripheral Board Code	301	301
S034	D20K Peripheral Board (supports B003)	D20K Peripheral Board Code	306	306
S035	D20C Peripheral Board (supports B003)	D20C Peripheral Board Code	307	307
S055-0	D20AC Peripheral Board (supports B003)	D20AC Peripheral Board Code	108	108

Firmware/FPGA versions

Table 3 lists the firmware, FPGA and other version information.

Table 3: Firmware/FPGA versions information

Component	Version	ID Type	ID	Date	How to Find
JMON	1.0.624-2209	N/A	N/A	Wed Aug 15 2012 09:44AM	"D20 Version" shown during cold boot sequence:.
Board	N/A	Board	D20MX	N/A	"Board ID" shown via SHELL command: si
Local Bus FPGA	3.02	N/A	N/A	N/A	"FPGA version" shown via SHELL command: si
NVRAM FPGA	21	File	15	N/A	"NVRAM Rev" shown via SHELL command: si
VxWorks O/S and BSP	v1.0/0	Build	0aeaed3881ca956f	Oct 7 2012, 16:13:38	SHELL command: ver
Application	v1.00	Build	673e5b3f1f38f219	Oct 8 2012 - 16:22:09	SHELL command: ver

D20 chassis

For a detailed description of the D20 chassis options and components, refer to Familiarization chapter in the *D20/D200 Installation and Operation Guide*, 994-0078. The D20MX supports the two versions of the D20 chassis listed in Table 4.

Table 4: Types of D20 chassis

Type	GE part number	Description
D20 non-VME 1 slot horizontal	500-0305	Chassis with backplane, external power connections, and 7 serial I/O ports
D20 VME 5 slot horizontal	500-0280	Chassis with 5 card VME backplane

D20 non-VME

The D20 non-VME single-slot chassis consists of the following:

- D20MX processor board
- Modem slots
- Power supply with switch and fuses; see Figure 1.

Figure 1: D20 non-VME chassis - power supply switch and fuses



This chassis contains the WESTERM D20M+ SS termination panel, which is attached directly to the back of the assembly; see Figure 2.

Figure 2: D20 non-VME backplane



D20 VME

The D20 VME-compatible chassis (see Figure 3) can support one D20MX main board. When using the D20MX in a VME chassis, the 0 V ground wire must be used.

Figure 3: D20 VME chassis - power supply switch and fuses



This chassis (see Figure 4) contains the WESTERM D20M+ termination panel that is mounted separately on the D20 chassis. The VME chassis kit includes a VME bus backplane, called the WESTERM D20VME. The VME bus backplane connects to the termination panel using a ribbon cable from Slot 1 on the bus backplane.

Figure 4: D20 VME chassis - VME bus backplane and D20M+ termination panel



Power supply

The chassis-mounted power supply modules are switch-mode converters that provide output power for the D20MX processor board, VME cards, modems and D20 Peripheral I/O modules, as required. A redundant power supply can be installed to provide fail-over protection to ensure continuous power to the D20.

If you have an extended system with more than five peripherals, the chassis-mounted D20 power supply is not adequate. In this case, you need to install an external power supply.

Table 5 lists the standard power supplies that are available. Other power supplies are available for specific requirements. Contact GE Digital Energy for details.

Table 5: Available power supplies

GE part number	Input	Output
580-2004	20 to 60 V DC	+5 V, 7 A; +12 V, 2 A; -12 V, 1 A; 24 V DC, 3 A
580-2005	20 to 60 V DC	+5 V, 7 A; +12 V, 2 A; -12 V, 1 A; 48 V DC, 1.5 A
580-2006	100 to 300 V DC or 85 to 264 V AC	+5 V, 7 A; +12 V, 2 A; -12 V, 1 A; 24 V DC, 3 A
580-2007	100 to 300 V DC or 85 to 264 V AC	+5 V, 7 A; +12 V, 2 A; -12 V, 1 A; 48 V DC, 1.5 A

NOTICE

Ensure your D20 power input is externally protected for over-current; otherwise damage to the D20MX may occur. The required fuse rating depends on the power consumption of your system.

The D20 available power supplies, listed in Table 5 are equipped with two field replaceable fuses.; see Figure 5.

Figure 5: D20 - Location of field-replaceable fuses



Field-replaceable fuses for the standard chassis-mounted Power Supplies are listed in Table 6. These are the standard factory-installed fuses, unless otherwise specified. Always replace with the same type and values of fuse.

Table 6: Field-replaceable fuses

Power Supply	Fuse	Fuse Function	Replacement Fuse (¼inch by 1 ¼ inch Time Delay)
580 - 2004	F1	+DC Input	12 A / 250 V
	F2	-DC Input	12 A / 250 V
580 - 2005	F1	+DC Input	12 A / 250 V
	F2	-DC Input	12 A / 250 V
580 - 2006	F1	Line/+DC Input	4 A / 250 V
	F2	Neutral/-DC Input	4 A / 250 V
580 - 2007	F1	Line/+DC Input	4 A / 250 V
	F2	Neutral/-DC Input	4 A / 250 V

Modems

Two D20 modems (can be purchased separately) for communications to a host computer or to other IEDs:

- WESDAC 202/V.23 is a 1200-baud Bell 202 or CCITT V.23 standard modem designed for 300 to 1200 baud asynchronous operation on unconditioned lines and supports the majority of SCADA/EMS applications. It is available in a 19 inch rack mount or 3U vertical mount configuration in the D20 chassis.
- WESDAC 212/V.23 is a 1200-baud Bell 212 standard modem, (auto answer only), used for dial-up access to the D20. This modem is available for mounting only as a 3U vertical mount.

Third-party modems can be used to meet specific requirements. These modems are connected to the D20 via standard RS-232 connections. Contact GE Digital Energy for more information on options.

Peripherals

Peripheral I/O modules are intelligent modules containing an on-board microprocessor. They are configured as slaves to the D20MX processor board. In this way, specific I/O processing is distributed throughout the RTU to the appropriate I/O module.

There are five types of I/O peripherals:

- D20A analog input
- D20S digital inputs
- D20K digital output
- D20C combination input/output
- D20AC alternating current analog input

Optional high-voltage peripherals are also available.

Ordering guide

The latest D20MX Processor ordering guide is available on the GE Digital Energy website:

http://www.gedigitalenergy.com/multilin/energy/catalog/D20MX.htm

You can select the required options from the available Product Option items. The Order Code automatically updates as each option is selected.

The Order Codes are listed in Table 7.

Table 7: D20MX order codes

Order Code Item	D20MX	-C	X	X	P	-M	M	M	-P	F
D20MX CPU Options										
(A) - D20MX non-VME, dual 10/100/1000BASE-TX Ethernet Ports (front access)		A								
(C) - D20MX non-VME dual 100BASE-FX Ethernet Ports (front access)		C								
(E) - D20MX non-VME, dual 10/100/1000BASE-TX (front access), conformal coated		E								
(F) - D20MX non-VME, dual 100BASE-FX Ethernet Ports (front access), conformal coated		F								
(G) - D20MX non-VME, dual 100BASE-FX Ethernet Ports (rear access)		G								
(H) - D20MX non-VME, dual 100BASE-FX Ethernet Ports (rear access), conformal coated		H								
D20MX Power Supply										
(U) - Not required					U					
(A) - D20 Power Supply, 20-60VDC Input, 24V ISO Output					A					
(B) - D20 Power Supply, 20-60VDC Input, 48V ISO Output					B					
(C) - D20 Power Supply, 100-300VDC/85-264VAC Input, 24V ISO Output					C					
(D) - D20 Power Supply, 100-300VDC/85-264VAC Input, 48V ISO Output					D					
D20MX Modem slots 1, 2 & 3										
(U) - Empty slot with cover plate						U	U	U		
(A) - Wesdac D20 202 bin modem						A	A	A		
(C) - Telenetics 14400 baud modem 2-wire dial up						C	C	C		
(D) - Telenetics 14400 baud modem 4-wire leased line						D				
(E) - D20MX dual 100BASE-FX ST Media Interface Card						E				
(F) - D20MX dual 100 BASE-FX LC Media Interface Card						F				
D20MX Serial Termination Panel Options										
(U) - Not required									U	
(A) - Rack Mounted SIO Westerm Panel									A	
(B) - Rear Mounted SIO Westerm Panel									B	
(C) - Rack Mounted SIO Westerm Panel w/Extended Bracket									C	
D20MX firmware options										
(A) -D20MX firmware v1.00, B021(v988) / B009(v400)										A
(B) -D20MX firmware v1.00 - B021(v912) / B009(v310)										B

D20MX upgrade kits

Table 8 lists the available D20 MX upgrade kits.

Table 8: D20MX upgrade kits

Part Number	Description
D20MX-N-SET-F-XX-X	D20MX CPU, 2 x 10/100/1000 Base TX Front Access ports (RJ45)
D20MX-N-SEF-F-XX-X	D20MX CPU, 2 x 100 Base FX Front access ports (ST Connectors)
D20MX-N-SEF-R-XX-X	D20MX CPU, 2 x 100 Base FX Rear Access ports (ST Connectors)

Table 9 lists the parts provided in each D20MX upgrade kit.

Table 9: Upgrade kit parts

Part Number	Part Description	D20MX-N-SET-F-XX-X	D20MX-N-SEF-F-XX-X	D20MX-N-SEF-R-XX-X
526-3001	D20MX CPU non VME 2x10/100/1000 BaseTX	1		
526-3003	D20MX CPU non VME 2x100 BaseFX (Front Access)		1	
526-3005	D20MX CPU non VME 2x100 BaseFX (Rear Access)			1
526-3104	D20MX 100Base-FX Rear ST FO Card			1
975-1236	D20MX CPU to D20MX Rear FO Card Harness			1
975-1237	Termination panel to Backplane 0 V Harness	1	1	1
953-1014	Blank Plate for D20MX Install	1	1	1
953-1015	Lower filler cover plate	1	1	1
581-0002	GE Digital Energy Products Documentation CD	1	1	1
588-0075/00	GE Digital Energy D20MX Documentation CD	1	1	1
588-0077/00	GE Digital Energy SGConfig 7.0 Setup Software DVD	1	1	1
977-0529/72	Cable, Null Modem DB9F-DB9F, 80 °C, 150 V	1	1	1
460-0073	Ferrite clamp	1	1	1

Product specifications

The D20MX adheres to the following system, communications, electrical, physical and environmental specifications. Additional Standards and Protection are listed in Appendix A, *Standards & Protection*.

System

Processor	667 MHz embedded PowerQUICC II Pro
Memory	1024 MB of 266 MHz DDR2 RAM with ECC 16 MB NVRAM for persistent event storage
Storage	8 MB boot flash 256 MB firmware flash
Operating system	VxWorks
LED indicators	System status: Power, Ready Ethernet port status: Link and Activity status per port Power supply: Power IRIG: Flashes when active.

Communications

Network connections	Dual redundant Ethernet interface Twisted Pair 10/100/1000BaseT (Isolated RJ-45 connector) 100BaseFX (Fiber Optic: 1300 nm, 50/125 µm, 62.5/125 µm multi-mode duplex fiber cable, ST connectors)
Serial communications	**D.20 Link, 2 channels** Data rate: 250 kbps Surge protected to ±2000 V peak **RS-232, 7 channels** 5-signal (TXD, RXD, RTS#, CTS#, DCD#) DTE ports Data rate: independently-selectable; refer to the application configuration guides.
Maintenance Port	RS-232, 1 channel/ 2 ports 2-signal (TXD, RXD) Data rate: 19200 (default)

Electrical

Rated power supplies	**AC-DC**	100 to 240 V AC (±10%) 143 W output maximum Minimum/Maximum AC voltage: 90 V AC / 265 V AC 100 to 300 V DC (±10%) 143 W output maximum Minimum/Maximum DC voltage: 88 V DC / 330 V DC
	DC-DC	20 to 55 V DC (±10%) 135 W maximum Minimum/Maximum DC voltage: 18 V DC / 60 V DC
Peak inrush current at 25 °C on cold start	**AC-DC**	50 A, max at 230 V AC
	DC-DC	50 A, max at 230 V AC
Rated frequency (AC-DC)	50/60 Hz nominal (47 to 63 Hz)	

Physical

Overall height	40.34 mm (1.588 in.)
Width	261.87 mm (10.31 in.)
Depth	160 mm (6.3 in.)
D20MX weight	0.7 kg (1.65 lb)
Fiber card weight	0.2 kg (0.35 lb)
Battery shipping restrictions	The D20MX does not contain a battery and is therefore not affected by US DOT or ICAO shipping restrictions.
Material/Finish	Galvannealed steel with black power coat
Kit package	Length: 49.5 cm (19.5 in.) Width: 34.3 cm (13.5 in.) Height: 15.2 cm (6 in.) Weight: 2.54 kg (5.6 lb)

Environmental

Operating temperature	0°C to +70°C **Note:** Do not operate the D20MX above 60°C for extended periods of time as this will shorten the life of the super capacitor and reduce the backup time of the real time clock.
Humidity rating	5% to 95% relative humidity, non-condensing
Environmental rating	Ingress protection: IP30 (IEC 60529)
Installation / overvoltage category	CAT II (2)
Pollution degree	2
Use	Indoor use only
Operating altitude	Maximum altitude 3000 m [9480 feet] above sea level
MTBF (MIL-HDBK-217): D20MX processor board	Non-VME with 10/100/1000BASE-TX copper: 449,616 hours at 40°C Non-VME with 100BASE-FX fiber optic: 265,657 hours at 40°C

Software

Configuration	Performed using SGConfig 7 and higher

SOE time stamp accuracy

Time Sync	IRIG-B
Test	Status point on D20S peripheral toggled at 1 pulse per second, synchronized to a GPS time signal. D20MX running under load.
Performance	99% of 1 pulse per second events are within ± 1 ms, and 100% of the events are within ± 2 ms over a 15 hour period

Storage recommendations

Storage conditions

Always store the D20MX in an environment compatible with operating conditions. Recommended environmental conditions for storage are:

- Temperature: -40 °C to +85 °C
- Relative humidity: 5% to 95%, non-condensing
- Maximum altitude: 12192 m [40,000 feet] above sea level

Do not store the D20MX above 60°C for extended periods of time as this will shorten the life of the super capacitor and reduce the backup time of the real time clock.

When powered off, the D20MX real time clock will remain active for 14 days at -40°C to 60°C, and greater than one month at 25°C. Information in the NVRAM will remain stored indefinitely as flash memory is used.

D20MX Processor

Chapter 2: Installing the D20MX

This chapter covers the following topics:

- D20 chassis layouts
- Overview of the steps and tools required to install the D20MX
- Retrofitting the D20MX in an existing D20
- Grounding the D20MX and connecting the power supply

D20 chassis layouts

Installation of the D20MX can be performed with one of three D20 chassis layouts; see “Installation steps” on page 31.

The D20 non-VME chassis front panel layouts for the D20MX upgrade kits comprise:

- A D20 containing a D20MX with front Ethernet connectors; see Figure 6.
- A D20 containing a D20MX with front Fiber Optic connectors; see Figure 7.
- A D20 containing a D20MX with rear Fiber Optic connectors; see Figure 8.

Figure 6: D20 chassis front panel - D20MX with Ethernet connectors



Figure 7: D20 chassis front panel - D20MX with front fiber optic connectors



Figure 8: D20 chassis front panel - D20MX with rear fiber optic connectors



Installation steps

The D20MX can be installed in a non-VME (GE part number 500-0305) or VME (GE part number 500-0280) D20 chassis. If you are retrofitting an existing D20 device, See section: "Retrofitting the D20MX in an existing D20" on page 33.

To install the D20MX in a D20 chassis

1. Ensure that you are sufficiently grounded to prevent ESD damage to the D20MX or other components. See section: "Grounding the D20MX" on page 36.
2. Remove the D20MX from its static-protective packaging. Set the packaging aside and save it for future reuse. See section: "Unpacking the D20MX" on page 36.

NOTE

The D20MX must be placed on an anti-static surface while not installed in the chassis.

3. Remove all horizontal blank faceplates.
4. Gently install the D20MX in the first (bottom-most) slot. Align the edge of the D20MX with the guide rails in the D20 chassis.

NOTE

The D20MX is a double-height board that occupies two slots in the chassis.
Handle the D20MX with care, since SMT components are located on the bottom side.

5. Push the front panel of the D20MX until it is seated properly and firmly connected to the backplane of the chassis.
6. Tighten the front panel retaining screws to 3.5 in-lbs to secure the D20MX to the chassis.
7. For the 526-3005LF version:
   - 7.1. Remove the position 1 and position 2 vertical blank plates from the D20 chassis.
   - 7.2. Remove the D20MX Fiber Card from the static-protective packaging.

7.3. Connect the 20-pin header end of the cable (part number 975-1236) to connector P1 on the fiber optic daughter card.

7.4. Secure the cable to the fiber optic daughter card with a cable tie.

7.5. Insert the fiber optic daughter card partially into the chassis, and feed the other ends of the cable through the middle slot in the chassis wall between the VME slots and the peripheral slots.

7.6. Connect the other end of the cable (with two connectors) to the D20MX connectors J3 (shorter length of cable) and J4 (longer length of cable).

See Figure 11, "Cable to fiber optic daughter card," on page 34.

Ensure that the cable is not pinched.

7.7. Push the front panel of the fiber optic daughter card until it is fully inserted.

7.8. Tighten the front panel retaining screws to 3.5 in-lbs to secure the fiber optic daughter card to the chassis.

8. Install the new lower filler plate (part number 953-1015).
9. Install the new filler plate (part number 953-1014) in the space above the D20MX.
10. Attach any required communication cables to the connectors on the front panel of the D20MX or the backplane of the D20 chassis.
11. If the D20MX is being installed in a VME chassis, connect the 0 V cable (part number 975-1237):

    11.1. Connect the bare end of the cable wire to the O V connector on the WESTERM terminal block TB2-9.

    11.2. Remove the wire from the lower 0 V connector on the VME backplane and connect this wire to the male end of the 0 V cable.

    11.3. Connect the female end of the 0 V cable to the lower 0 V connector on the VME backplane.

    See *Figure 12, "0 V cable connection"*.

12. Install the ferrite clamp if necessary.

    If you ordered a complete D20 system including the D20MX, notice that a ferrite clamp has already been attached to the power cable. Go to step 13.

    If you ordered a D20MX upgrade kit, a ferrite clamp included in the package is to be attached to the power inlet cable:

    12.1. Ensure that you are sufficiently grounded to prevent ESD damage to the D20MX or other components. See "Grounding the D20MX" on page 36..

    12.2. Remove ferrite clamp (GE part number 460-0073) from the package; handle with care as the magnetic material is fragile.

    12.3. Pass the power cable through the channel, approximately 15 cm (6 inches) from the connector on the chassis.

    12.4. Loop the power cable one more time around and through the core. See Figure 9.

Figure 9: Open ferrite clamp



12.5. Close the core and snap the halves together. See Figure 10.

Figure 10: Closed ferrite clamp

12.6. Visually inspect the installation and confirm that the assembly has completely latched and that the power cable is not pinched. Also check that none of the power cable connections have come loose during the installation process.

13. Connect the power supply to the D20 chassis. See section: "Connecting the power supply" on page 37.
14. Power-up the D20. See Chapter 4, *Powering-up and Testing*.
15. Start using the D20MX's tools and utilities to configure and monitor the operation of the D20MX. See Chapter 6, *Using the D20MX*.
16. Make device and network connections. See *Chapter 3, Connecting to Devices and Networks*.

Retrofitting the D20MX in an existing D20

The D20MX processor board can be installed in an existing D20 device to replace D20ME D20M++, or D20MEII processor boards. If a D20 is being retrofitted, the following limitations exist:

- You cannot install multiple D20MX processor boards in a single D20. Therefore, a maximum of seven serial and two D.20 Link connections are supported on each D20 unit.
- The D20MX supports 100BASE-FX instead of 10BASE-FL. If you are using any other devices in your system, and you are limited to 10BASE-FL, you must purchase a 100BASE-FX to 10BASE-FL media converter.

The D20MX can be installed in a VME chassis or a non-VME chassis.

See section: "D20MX upgrade kits" on page 24 for a list of available upgrade kits and the parts provided within each kit.

To retrofit the VME chassis and the non-VME chassis

1. Ensure that you are sufficiently grounded to prevent ESD damage to the D20MX or other components. See section: *"Grounding the D20MX" on page 36*.
2. Switch the power off for the D20 chassis.
3. Remove the D20ME, D20M++, or D20ME II module.
4. Remove the D20EME module and D20EME Media Interface Card.
5. Remove the horizontal blank faceplates, including the bottom faceplate.
6. If the chassis contains a modem card, move the modem card to position 2.
7. Follow the D20MX "Installation steps" on page 31.
   See *Figure 11, "Cable to fiber optic daughter card"*.
   Ensure that the cable is not pinched.

Figure 11: Cable to fiber optic daughter card



8. If the D20MX is being installed in a VME chassis, connect the 0 V cable (part number 975-1237):
   - 8.1. Connect the bare end of the 0 V cable wire to the O V connector on the WESTERM terminal block TB2-9.
   - 8.2. Remove the wire from the lower 0 V connector on the VME backplane and connect this wire to the male end of the 0 V cable.
   - 8.3. Connect the female end of the 0 V cable to the lower 0 V connector on the VME backplane.

   See *Figure 12, "0 V cable connection"*.

Figure 12: 0 V cable connection



Required tools and materials

Before beginning the installation procedures, have the following tools and equipment available:

- Appropriate device cables for D.20 connections (GE part number 977-0089)
- For D20MX Non-VME with Dual 10/100/1000Base-TX (part number 526-3001): CAT5 network cables for RJ-45 Ethernet connections (GE part number 977-0280 or equivalent)
- For D20MX Non-VME with Dual 100Base-FX (part number 526-3003) and D20MX Non-VME with Dual 100Base-FX Fiber Optic Card (part number 526-3005): multi-mode duplex fiber cable - ST connectors.
- Flathead screwdriver with 0.6 mm by 3.5 mm blade (for terminal block wiring)
- #1 Phillips screwdriver (for panel or DIN rail mounting the unit)
- #2 Phillips screwdriver (for rack mounting the unit)
- Needle-nose pliers
- Wire cutters
- Wire strippers
- Approved network settings for the device
- Windows-based PC with any Windows-based terminal emulation software and Web browser software installed
- 12 AWG wire (minimum) for protective earth
- 2 ring connectors, Panduit part number PV10-14R for 12 AWG [3.3 mm^2] wire for protective earth terminal

Grounding the D20MX

Surge and noise suppression components used on the D20MX are designed to prevent nuisance operation and damage to internal components. To ensure correct protective operation, the earth ground wire (14AWG green wire) on the D20 chassis must be connected to a low impedance ground rail of a secondary cabinet or rack.

When making ground connections, ensure that all surfaces that are used for grounding are free of dirt, residue and corrosion.

NOTICE

Do not power up the D20 before establishing a proper protective earth connection.

Unpacking the D20MX

Carefully remove the D20MX from its packaging. Visually inspect the unit to ensure it has not sustained any visible damage during transit. If there are visible signs of damage, *report it immediately to the carrier.*

Package contents

The following items are provided as part of your D20MX shipment:

- D20MX unit (GE part number 526-3001, or 526-3003, or 526-3005)
- For 526-3005LF only:
  - D20MX to Fiber Card Harness (975-1236)
  - D20MX 100BASE-FX Rear LC FO Card (part number 526-3103LF) or D20MX 100BASE-FX Rear ST FO Card (part number 526-3104LF)
- Lower filler plate (part number 953-1015)
- Blank plate for D20MX install (part number 953-1014)
- 0 V wire cable (part number 975-1237)
- For 526-3005LF installed in 500-0280 only:
  - Termination Panel, D20MX extended mounting (952-2087)
- GE Digital Energy Product Documentation CD (GE part number 581-0002)
- GE Digital Energy D20MX Documentation CD (GE part number 588-0075/00)
- SGConfig Tool CD providing device configuration software (GE part number 588-0077/00)

Verify that you have received all items. GE parts include a unique number, typically in the format XXX-XXXX, that can be used as a reference.

Connecting the power supply

The D20MX processor board is supplied power through the WESTERM D20M+ SS backplane. Power connections to the backplane are made on connector block TB1.

For the WESTERM D20M+ SS and WESTERM D20M+ (see Figure 13, "WESTERM D20M+SS: power supply connections") the power supply connections:

- 1 & 2 are used for input power connections based on the D20 power supply
- 4 & 5 can be used as a switched auxiliary power supply source
- 7 & 8 can be used externally for status wetting, contact wetting and/or miscellaneous power connections, if applicable.

Figure 13: WESTERM D20M+SS: power supply connections



D20MX Processor

Chapter 3: Connecting to Devices and Networks

This chapter provides guidelines for making physical connections between the D20 and substation and network devices.

Cabling overview

All physical connections are made to the connectors on the rear backplane of the D20 chassis or to the front on the D20MX processor module.

D20MX front panel connectors

The D20MX front panel can have one of the following layouts:

- Ethernet connectors (RJ45); see Figure 14.
- Front access Fiber optic connectors (ST); see Figure 15.
- Rear access Fiber optic connectors (ST) on a fiber optic daughter card; see Figure 16.

For a description of the operational status LEDs and port status LEDs, see “Front panel LEDs ” on page 81.

Figure 14: D20MX front panel with Ethernet connectors



Figure 15: D20MX front panel with front access fiber optic connectors



Figure 16: D20MX front panel and fiber optic card with rear access fiber optic connectors



General cabling requirements

Table 10 lists the cables required to connect to the D20MX:

Table 10: Connection cables

Media	Designation	Cabling	Connector
Serial	RS-232	Shielded	DB-9 female
D.20 Link	RS-485 2 wire	Shielded	DB-9 female
Twisted Pair Ethernet (GE part number 526-3001 only)	10/100/1000BASE-T	UTP (Unshielded Twisted Pair) – CAT 5 or better	RJ-45
Fiber optic (GE part number 526-3003 and 526-3005LF only)	100BASE-FX	1300 nm, 50/125 µm and 62.5/125 µm multimode duplex fiber cable	ST-style connectors

To provide higher EMC immunity and maintain CE Mark radiated emission compliance, the serial cables used for permanent serial and D.20 Link connections must comply with the following requirements:

- Cables must be shielded
- D-type connector covers must provide EMC shielding (e.g. metallized plastic or die cast metal covers).

Serial

Seven serial communications ports are brought out to the backplane connector P2. These serial ports are five-signal (TXD, RXD, RTS#, CTS#, DCD#) DTE serial ports, compliant to ANSI/TIA-232 and TIA/EIA-694 specifications and are hosted by UARTs.

The D20MX is tested with all 7 serial ports running at 19200 baud with 20% CPU utilization. Refer to application configuration guides for supported baud rates and for data bits.

NOTICE

To avoid burning out the WESTERM or D20MX mainboard when directly connecting a rear-panel serial port on one D20MX chassis to another rear-panel serial port on any type of D20 chassis, jumper the WESTERM of both chassis' to not provide a power connection to pin 4. Refer to the appropriate WESTERM module layout for jumper settings.

D.20 Link

Communications between the D20 and the D20 peripheral I/O modules are carried over a high-speed, high-level data link control (HDLC) protocol called the D.20 Link. The D.20 Link has the following features:

- RS-485 serial link, half duplex, 250 kbps
- D.20 frame using HDLC protocol format with Manchester encoding
- Supports up to 31 D20 I/O peripheral modules in a standard configuration
- Repeater/extension modules (GE part number 520-0148) may be used to extend this limit to a maximum of 120 peripheral modules. The D20MX is compatible only with certain peripheral common code (i.e., pcommon) versions as defined in Table 11.

Table 11: PCOMMON versions compatible with the D20MX

PCOMMON Description	Versions compatible with the D20MX
P022 - PCOMMON for D20C	3.0x
P010 - PCOMMON for D20A, D20S and D20K	3.0x
P087 - pBOOT for D20AC	104

Twisted-pair Ethernet (for 526-3001 only)

The10/100/1000BASE-T variant of the D20MX can connect to one or two networks through two twisted-pair Ethernet connections. In single-IP mode this causes the two Ethernet connections to use the same MAC address and IP address. Port 1 is the primary port and Port 2 is the secondary port. When the system detects a signal on Port 1, Ethernet traffic takes place on Port 1. When the system detects loss of signal on Port 1, Ethernet traffic takes place on port 2.

All RJ-45 connectors have the same signal definition. However, the twisted-pair Ethernet ports are auto MDI/MDIX and can support a straight-through or crossover cable.

NOTE

External switches must have Spanning Tree Protocol port settings configured to edge for proper operation.

To connect the D20MX to network devices

Plug network cables into the D20MX twisted-pair Ethernet ports.

NOTE

If the D20MX is deployed in the presence of strong RF energy in the 110 MHz - 125 MHz band, such as airport ILS localizers or aviation radio transmitters, it is recommended that shielded twisted-pair Ethernet cables be used.

Table 12: Ethernet RJ-45 connector signal definitions

Position	Function	Signal Flow	Color
1	RX+	IN	White w/ Orange
2	RX-	IN	Orange
3	TX+	OUT	White w/ Green
4	P1+	-	Blue
5	P1-	-	White w/ Blue
6	TX-	OUT	Green
7	P2+	-	White w/ Brown
8	P2-	-	Brown
	Shield	-	-

Table 13: Ethernet crossover cable (RJ-45) pin out

D20MX		Switch/Hub	
Name	Pin	Pin	Name
TX_D1+	1	3	RX_D2+
TX_D1-	2	6	RX_D2-
RX_D2+	3	1	TX_D1+
RX_D2-	4	2	TX_D1-
BI_D3+	5	7	BI_D4+
BI_D3-	6	8	BI_D4-
BI_D4+	7	4	BI_D3+
BI_D4-	8	5	BI_D3-

Table 14: Ethernet straight-through cable (RJ-45) pin 0ut

D20MX		PC	
Name	**Pin**	**Pin**	**Name**
TX_D1+	1	1	RX_D2+
TX_D1-	2	2	RX_D2-
RX_D2+	3	3	TX_D1+
RX_D2-	4	4	TX_D1-
BI_D3+	5	5	BI_D4+
BI_D3-	6	6	BI_D4-
BI_D4+	7	7	BI_D3+
BI_D4-	8	8	BI_D3-

Fiber optic Ethernet (for 526-3003 and 526-3005LF only)

The 100BASE-FX variant of the D20MX (GE part numbers 526-3003 and 526-3005) can connect to one or two networks through two fiber-optic Ethernet connections.

The data rate on each port is 100 Mbps.

NOTE

You must enable Far End Fault Indication (FEFI) or Loss Link Alert (LLA) in connected external devices for proper redundant operation.

NOTE

External switches must have Spanning Tree Protocol port settings configured to edge for proper operation of 100Base-FX connected ports.

You can use the following glass optical fiber (GOF) cabling with the D20MX:

- 50/125 µm core/cladding multi-mode (gradient index) cable
- 62.5/125 µm core cladding multi-mode (gradient index) cable
- 100/140 µm core/cladding multi-mode (gradient index) cable
- 200 m core Hard-Clad Silica (HCS) multi-mode (step index) cable

You can use the following fiber optic terminations for D20MX cabling:

- ST Connectors (with 526-3003 and 526-3005LF + 526-3104LF fiber card)
- LC connectors (with 526-3005LF + 526-3103LF fiber card)

When calculating cable length, consider the following optical power levels:

- Glass optical fiber transmitter power is –19.0 ± 2 dBm
- Glass optical fiber receiver sensitivity is typically –25.4 dBm

⚠CAUTION

This product contains components rated as Class 1 Laser Products.

LAN redundancy

Both twisted-pair and fiber optic Ethernet options provide two LAN redundancy schemes called single-IP redundancy and dual-IP redundancy.

Single-IP redundancy provides automated fail over between two Ethernet network connections (TX1/RX1 and TX2/RX2) that share a single MAC and IP address.

When the primary port (that is, port 1) receives no signal, or detects a fault signal from the remote link partner, the D20MX switches to the secondary port (that is, port 2) if it has a valid link. The D20MX reverts to the primary port if the primary link is restored or no signal is present on the secondary port.

With dual-IP redundancy, each port has a unique MAC, IP address and subnet. Each remote device participating in dual-IP redundancy must have a primary IP address reachable through the subnet of port 1 of the D20MX and a secondary IP address reachable through the subnet of port 2 of the D20MX. D20MX client applications will fail over to the remote device's secondary IP address when they detect a failure to communicate with the remote device's primary IP address. D20MX server applications accept communications from the remote device's primary or secondary IP address.

To configure a system for single-IP redundancy, enable only LAN A in the device properties of the D20MX. To configure a system for dual-IP redundancy, enable both LAN A and LAN B in the device properties of the D20MX. The D20MX device properties may be configured through SGConfig 7 and higher.

IP addresses

The D20MX assigns IP configuration to its LAN A and optionally LAN B interface according to the rules defined in Table 15.

In a standalone system, the D20MX assigns the LAN A and LAN B IP addresses exactly as you configured them in SGConfig.

In a redundant system, the D20MX assigns the LAN A and LAN B IP addresses of the Active CCU exactly as you configured them in SGConfig.

However, in other modes, the CCU assigns derived IP addresses as indicated in Table 15. For a description of the modes, refer to Table 17. The D20MX assigns the subnet mask of the derived IP addresses as the subnet mask configured in the LAN A or LAN B configuration.

Table 15: D20MX IP address assignment

CCU	Redundant System	Mode	LAN A IP Configuration	LAN B IP Configuration (If Configured)
CCU A	Standalone	Active, Debug or Disabled	**IP Address**: LAN A IP Address **Mask**: LAN B Subnet Mask (e.g 192.168.1.1 / 255.255.255.0)	**IP Address**: LAN B IP Address **Mask**: Configured LAN B Subnet Mask (e.g. 192.168.2.1 / 255.255.255.0)
CCU A	Redundant	Active		
CCU B	Redundant	Active		
CCU A	Redundant	Standby, Debug or Disabled.	**Derived IP Address**: LAN A IP Address + 1 **Mask**: LAN A subnet mask (e.g. 192.168.1.2 / 255.255.255.0)	**Derived IP Address**: LAN B IP Address + 1 **Mask**: LAN B subnet mask (e.g. 192.168.2.2 / 255.255.255.0)

CCU	Redundant System	Mode	LAN A IP Configuration	LAN B IP Configuration (If Configured)
CCU B	Redundant	Standby, Debug or Disabled.	**Derived IP Address**: LAN A IP Address + 2 **Mask**: LAN A subnet mask (e.g. 192.168.1.3 / 255.255.255.0)	**Derived IP Address**: LAN B IP Address + 2 **Mask**: LAN B subnet mask (e.g. 192.168.2.3 / 255.255.255.0)
CCU A/B	Redundant or Standalone	Service Mode	Not enabled	Not enabled

You may override or disable the derived IP address by defining a host with the desired IP address. Use an IP address of 0.0.0.0 to disable the derived IP address. Define the host in the SGConfig tool > D20 Device Wizard > Define the LAN properties for this project screen (see Figure 17 for an example).

Figure 17: SGConfig - example of overriding derived IP address by defining a hostname



Each host consists of a host name and host address. Construct the host name by replacing the last two characters of the D20 Host Name with a two character suffix that matches the derived IP address you wish to override or disable. The suffix conventions are shown in Table 16. The D20 Host Name appears in the D20 Device Wizard as shown in Figure 18.

Figure 18: SGConfig - Host name shown in the LAN Settings



Table 16: Host name suffix conventions

HostName Suffix	IP Address Corresponds To...	Example
AA	CCU A, LAN A	FAC_DEFAA
AB	CCU A, LAN B	FAC_DEFAB
BA	CCU B, LAN A	FAC_DEFBA
BB	CCU B, LAN B	FAC_DEFBB

The D20MX can be in one of five modes as defined in Table 17. You can find the current mode of the D20MX by navigating to the SHELL in WESMAINT II+ and typing the command **el**.

Table 17: System mode definitions

Mode	Description	Partial "el" output
Active	D20MX applications are operational.	`Active CCU YES`
Standby	D20MX applications are not operational but are ready to take over on a switchover command or a failover.	`Standby CCU YES`
Disabled	D20MX applications have been suspended due to an error. You must type **el /r** and **boot** in the SHELL to clear this error.	`Disabled YES`

Debug	D20MX boot sequence has been interrupted by pressing **CTRL-E**. Put the CCU into this mode in order to recover a system that has a corrupted configuration or code image.	`Redundant CCU NO`
		`Standby CCU NO`
		`Active CCU NO`
		`Service Mode NO`
		`Sys Service Mode NO`
		`Disabled NO`

Service Mode	D20MX configuration has been corrupted or is in the process of receiving a new configuration. To recover the system, you must download a configuration serially.	`Service Mode YES`

RS-232

The RS-232 port on the D20MX is used to access the WESMAINT II+ facility and to transfer code and configuration data to the D20MX. You can use a VT100-compatible terminal or terminal emulation program to directly access the WESMAINT II+ facility. SGConfig's Terminal Emulator is an example of a suitable terminal emulation program.

The RS-232 port is connected to the D20MX front panel and is also routed to the rear panel as (COM0). The default baud rate is 19,200.

Non-responsive RS-232 port

In the event that the D20MX RS-232 port appears non-responsive, type **Ctrl-Q**. This non-responsive condition might occur if your computer goes into sleep mode and then wakes up while still connected to the D20MX RS-232 port.

NOTICE

Use only a NULL modem cable (GE Energy part number 977-0529) when you are connecting to the D20MX front-panel RS-232 connector. Use of a WESMAINT cable will not allow communication to the D20MX.

NOTICE

Use only a standard WESMAINT cable (GE Energy part number 977-0300) when connecting to the rear panel COM0 connector. Use of a NULL modem cable will cause permanent damage to the D20MX and PC.

D20 system redundancy

A redundant D20 setup allows a secondary D20 to automatically take over operations from a paired D20 unit that has failed.

D20 equipment redundancy requires:

- Two D20 units and
- One or two RS-232 switch panels.

NOTE

The quiescent current of the +12 V power supply input on the RS-232 Switch Panel is 15 mA. The maximum power requirement on the +12 V input during operation is 230 mA.

Through a toggle switch on the RS-232 Switch Panel, you designate one of the CCUs as the Active unit. If the Active unit hardware or software fails, the Active CCU is automatically switched offline, and the Standby unit is switched through to the field equipment (i.e., it is made Active).

The RS-232 Switch Panel is not equipped with EMI protection circuitry. If the connection length exceeds 3m, a Serial Surge Protection Panel (GE item number 540-0249) or equivalent protection device should be installed.

Figure 19 shows a redundant D20 system, with CCU A active.

Figure 19: Redundant D20 system with CCU A active



If the Active CCU fails:

- The Standby CCU detects the failure through the inter-CCU communications link.
- The Standby CCU commands the RS-232 Switch Panel to switch over all serial connections.
- The RS-232 Switch Panel switches all serial field connections to the Standby CCU, which now becomes the Active CCU.

If CCU A fails, CCU B becomes active. See Figure 20, “Redundant D20 system - If CCU A fails”.

Figure 20: Redundant D20 system - If CCU A fails



Figure 21: RS-232 Switch panel



A pair of LEDs marked *CCU A* and *CCU B* indicate which of the D20 units is currently active. If the hardware or software of the active unit fails, it is automatically switched offline and serial connections to the field are transferred to the standby unit. A toggle switch on the RS-232 switch panel can be used to switch the D20 devices between active and standby modes.

Failover sequence

If the active D20 unit fails, the following actions occur:

1. The standby D20 unit detects the failure through the lack of a heartbeat signal on the ping cable or through a status change on the watchdog cable.
2. The standby D20 unit attempts to pull the RS-232 switch panel to assume the active state.
3. The RS-232 switch panel transfers all serial field connections to the standby D20, which then becomes the active D20.

Required components

To implement a redundant D20 system, you need the components: listed in Table 18.

Table 18: Redundant D20 system - required components

Component	Function	Part Number
RS-232 Switch Panel	Communications switch.	517-0247
Power Supply	Power supply to power the RS-232 switch panel. Input: 85 – 264 V AC or 90 – 350 V DC.	580-0046
Watchdog Cable Assembly	Connects D20 A to the RS-232 switch panel.	977-0160
	Connects D20 B to the RS-232 switch panel.	977-0160
Ping Cable Assembly	Links both D20 units to facilitate a heartbeat message that determines the status of the active unit.	977-0122
RS-232 Serial Cable	Connects the D20 to the RS-232 switch panel which is then connected to external field devices.	977-0121
Power/SysFail Cable	Connects the RS-232 switch panel to D20 external power supply.	970-0161
Ground Cable	Provides a ground connection for the RS-232 switch panel.	970-0182

NOTE

Pins 4 on switch panel connectors J2 through J9 are tied together and to the panel's power supply. Any loading from field devices on these pins will load the RS-232 panel power supply and should be taken into consideration when sizing power supplies.

To set up a redundant system

It is recommended that you install and configure one standalone D20 unit to ensure that your configuration is valid and that device communications are operating properly. Once this is done, proceed with the installation of the redundant system.

1. Mount the D20 units in a rack and connect power and ground.
2. Mount the RS-232 switch panel.
3. Plug the connector of watchdog cable A (GE part number 977-0160) to serial connector COM 6 on the first D20 (CCU A).
4. Connect the bare leads of watchdog cable A to TB1 (position 6-8) on the RS-232 switch panel.
5. Plug the connector of watchdog cable B (GE part number 977-0160) to serial connector COM 6 on the second D20 (CCU B).
6. Connect the bare leads of watchdog cable B to TB1 (position 14-16) on the RS-232 switch panel.
7. Connect the bare leads of both watchdog cables to TB1 on the RS-232 switch panel and the DB9 serial connector to either P1 or P9.
8. Connect one end of the ping cable to the first D20 and the other end to the second D20. This ping cable must be connected to the same serial port number on both units.
9. Use standard RS-232 cables (GE part number 977-0121) to connect the D20 serial communication ports to the serial ports on the RS-232 switch panel. P1 through P8 are connected to the first D20, P9 through P16 are connected to the second D20. Connections from the switch panel to both D20 units should be made in the same order. For example, if P1 is connected to port 3 on the first D20, P9 should also be connected to port 3 on the second D20.
10. Connect field devices to J1 through J8 on the RS-232 switch panel.

RS-232 switch panel operation

The RS2-32 switch panel has two sets of indicator LEDS:

- PWR A/PWR B: When lit, power and communications are received from the connected units. Normally, both LEDs are lit.
- CCU A/CCU B: Normally, one LED is lit, indicating which unit is active.

The active/standby switch on the front of the RS-232 switch panel is used to:

- Restore a previously failed unit to active status once it has been repaired.
- Manually force a unit to active status so that routine maintenance can be performed on the other unit.

To manually operate the RS-232 switch panel

1. Pull the active/standby switch straight out to release it from the locked position.
2. Switch it up to make unit A active or down to make unit B active.

The CCU A/CCU B LED indicator indicates which unit has been activated.

Redundancy wiring diagrams

Figure 22 illustrates how to wire the D20MX units and RS-232 switch panels to enable system redundancy:

NOTE

The D20MX watchdog (control) port, heartbeat (ping) port, and serial port assignments are software configurable. Refer to the *D2x Configuration Guides*.

Figure 22: Redundancy wiring - single RS-232 switch panel



D20MX Processor

Chapter 4: Powering-up and Testing

Once you have made all field wiring and communication connections and have completed the necessary hardware configuration, the next step is to power-up the D20MX and verify that it is functioning properly.

Use this chapter to prepare for and correctly perform the power-up and other tests. This chapter includes:

- What is needed to test: WESMAINT II+ facility, SHELL and SGConfig
- How to power-up the D20MX and conduct the BOOT Test: Power On Self-Test
- How to carry out a redundant system test

Before any of the tests and procedures in this section can be performed, a valid configuration file must be loaded into the D20MX NVRAM.

If you have replaced the main board of the D20MX, then you will need to restore the configuration file so that diagnostic tests can be performed.

If this power-up and test procedure reveals that your D20MX is not functioning properly due to software malfunction, then you need to download code and configuration files.

See the SGConfig online help.

Required for testing

The system components that are required for configuring and testing the D20MX are:

- WESMAINT II+ facility
- SHELL
- SGConfig application

NOTICE

To prevent burning out the main processor board, make two important checks before switching on the D20MX:

- Check that the external power supply input level is correct for the Power Supply fitted to the chassis. See section: “Power supply” on page 20.
- If you have 125 V DC or 110V AC input, then jumpers Z22 and Z23 on the WESTERM D20M+: 517 - 0225 or 517 - 0224 must be jumpered 2 - 3.

Accessing WESMAINT II+ using a terminal

You can use a VT100-compatible terminal or a terminal emulation program to directly access the WESMAINT II+ facility. SGConfig's Terminal Emulator is an example of a suitable terminal emulation program.

For further information about using WESMAINT II+ software to perform any of the test procedures in this section, refer to the *WESMAINT II+ User's Guide*.

Terminal Emulation

Microsoft Windows™ HyperTerminal can be used for terminal emulation but it is NOT recommended because code and configuration file download times are considerably increased.

The program Tera Term for Microsoft Windows™ does not have these limitations and is therefore recommended as a terminal emulation program. It can be downloaded from the Internet.

SHELL

The SHELL is a debugging and diagnostics tool that is accessible as a menu selection in WESMAINT II+, or from a basic login prompt if WESMAINT II+ is not available.

Power up and test steps

To power up and test the D20MX:

1. "Set up a PC to act as a WESMAINTII+ terminal". See page 55.
2. "Power up the D20MX" on page 55. See page 55.

   Result: The D20MX automatically runs the Online Start-up test. See "Automatic on-line start-up test" on page 55.
3. "Test for redundancy". See page 56.
4. "Check that fail-over is functioning correctly". See page 57.
5. "Check that switch-over is functioning correctly". See page 57.
6. "Verify either hardware or software switch-over". See page 58.

Set up a PC to act as a WESMAINTII+ terminal

To set up a PC to act as a WESMAINT II+ terminal.

1. Open the VT100 compatible terminal emulation software you are going to use.
2. Verify (or set) terminal communications settings as follows:

Setting	Value
Data Rate	19200 bps
Data Bits	8
Stop Bits	1
Parity	None
Flow Control	Xon/Xoff (software)
Connector Settings	COM1 or COM2, as required by the computer you are using

Result: The terminal emulator settings are now configured.

Power up the D20MX

To power up the D20MX

1. Check that all field wiring, grounding wires and fuses are in place and secure on your D20 system.
2. Turn the chassis-mounted Power Supply switch to ON.
   Result: The unit is powered-up.
3. On start-up, inspect the D20MX LED indicators on the front panel.
   Result: The RDY LED is flashing.

Automatic on-line start-up test

The D20MX automatically boots up when the power is switched on. Internal processes perform a series of routines. Self-diagnostic tests are performed followed by the spawning of all the software applications that reside in the unit's memory.

The self-diagnostic tests generate PASS or FAIL messages that can be viewed in your terminal emulator WESMAINT II+ screen. You can also see the results of the application spawning process.

Pass/Fail tests are carried out on the:

- User RAM
- NVRAM
- FLASH memory
- Root process

The self-diagnostics also return measures for:

- SDRAM size
- Bus Speeds
- CPU Core Speed

The NVRAM CRC test verifies that the configuration header is valid. If this fails, then the D20MX starts with a minimal set of applications that allow the system to be restored.

Code and configuration files

If the code and configuration files compiled for your specific system are already downloaded, then you can login straightaway to WESMAINT II+ for powering-up and testing.

If your system-specific code and configuration files are not downloaded, then you need to power-up with the default configuration. You can then login to the SHELL, download your system-specific files and restart the D20MX for testing.

For details, see the SGConfig online help.

Further testing

For further specific testing, log in to WESMAINT II+. See the WESMAINT II+ Users Guide and WESMAINT user guides for specific applications.

Test for redundancy

If you have a D20 redundant system, you must test that:

- CCU A and CCU B are communicating
- Fail-over is functioning correctly.

To check that CCU A and CCU B are communicating once you have powered-up the Primary and Secondary units:

1. On the front of the RS-232 Panel, check that CCU A LED is illuminated, which shows that CCU A is Active.

Both the PWR A and PWR B LEDs should be illuminated.

2. Connect a NULL modem cable (GE Energy part number 977-0529) to the RS-232 connector on the front panel of the active D20MX.
3. Attach the other end of the cable to the serial communications port of the PC or terminal.
4. Login to WESMAINT II+ through the emulator you are using.

   Result: The WESMAINT Main Menu is displayed.
5. Check to see that STNBY appears at the top-left of this WESMAINT screen.

   Results: If this text shows, then the Primary and Secondary CCU are communicating.

   If this text does not show, then the Primary and Secondary are not communicating.

STNBY appears on the Active CCU WESMAINT Main Menu display approximately one minute after power-up of the two units. Wait for this message to appear before following the next procedure.

Check that fail-over is functioning correctly

To check that fail-over is functioning correctly for the event of hardware failure:

1. On the front of the RS-232 Panel, check that CCU A LED is illuminated, which shows that CCU A is Active.

Both the PWR A and PWR B LEDs should be illuminated.

2. To simulate hardware failure, switch off the Active D20MX at the main power switch on the front of the unit.

   Result: If the RS-232 is functioning correctly, then it will switch over to the Standby unit and the CCU B LED will illuminate and the CCU A LED will go off.

Check that switch-over is functioning correctly

To check that switch-over is functioning correctly for the event of software failure:

1. On the front of the RS-232 Panel, check that CCU A LED is illuminated, which shows that CCU A is Active.

Both the PWR A and PWR B LEDs should be illuminated.

2. Connect a NULL modem cable (GE Energy part number 977-0529) to the RS-232 connector on the front panel of the D20MX designated as CCU A.
3. Attach the other end of the cable to the serial communications port of the PC or terminal.
4. Login to WESMAINT II+ on CCU A using your terminal emulator.

   Result: The WESMAINT Main Menu appears.
5. Select **Main Menu** > **System Functions** and press **ENTER**.

   Result: The WESMAINT Function Menu appears.
6. Select **SWITCH-OVER** on the **Function Menu** and press **ENTER**.

   Result: A password prompt appears.
7. Enter your password and press **ENTER**. The default password is *control*.

   Result: The CCU Switch-Over display appears.
8. Press **Ctrl-V** to begin switch-over.

   Result: A confirmation message appears: *Confirm Yes/No*.
9. Type **Yes** and press **ENTER**.

   Result: Fail over occurs

Verify either hardware or software switch-over

To verify either hardware or software switch-over.

1. Connect a NULL modem cable (GE Energy part number 977-0529) to the RS-232 connector on the front panel of the D20MX designated as CCU B, which was originally the Standby unit.
2. Attach the other end of the cable to the serial communications port of the PC or terminal.
3. Login to WESMAINT II+ through the emulator you are using.

   Result: The WESMAINT Main Menu is displayed.
4. If you can login to WESMAINT II+, this indicates that CCU B is the Active CCU.

   Results: Fail over has occurred.

NOTE

If the previously Active A CCU powers-up after a fail-over from CCU A to CCU B, then STNBY appears at top left when you login to WESMAINT II+ on CCU B. This can take up to a minute to occur.

NOTE

If you cannot login to WESMAINT II+ on a CCU, then the unit is most likely powered down. Verify that the RDY LED is flashing and verify that the serial cable is connected correctly.

D20MX Processor

Chapter 5: Configuring the Software

This chapter provides:

- An introduction to the software components used in the D20MX.
- An overview of the software tools you will use.
- How to download image files to the Flash memory on your D20MX module on your system using a serial or network connection.
- A description of the SGConfig™ firmware options
- How to update to the SAN0001 firmware option
- How to transfer D20/D200 configurations to the D20MX
- How to update D20/D200 configurations to use the D20MX firmware definition

Introduction to the D20MX software

The D20MX main processor board requires three valid files to be loaded:

- An operating system image file, called “vxWorks”, which resides in the file system on Flash memory
- An application image file, called “appl.out”, which resides in the file system on Flash memory
- A configuration file which resides in the NVRAM

Use this section to load the image files of your RTU system.

D20MX user accounts

The D20MX supports remote and local user accounts. Use remote user accounts whenever possible to increase the level of security and to decrease user administration effort. To implement remote user accounts, the D20MX uses Remote Authentication Dial-In User Service (RADIUS) with CHAP and EAP-TTLS authentication methods. Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for details on how to configure the D20MX to use RADIUS.

When RADIUS is used, your RADIUS server provides a role ID to the D20MX. The role ID defines which commands and displays the user is allowed to access while logged in to the D20MX. To allow your RADIUS server to provide a role ID, configure your RADIUS server to use the GE vendor profile that is common to many Multilin products. Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for details on how to configure your RADIUS server and the D20MX with the GE vendor profile. Also refer to Appendix A, *Default Role-Based Access Control Model* for the default role based access control model provided with the D20MX default configurations.

In the event all configured RADIUS servers are down or if RADIUS is not configured, the D20MX authenticates the user against the local configuration and password file. Local users are created with a default password of **changeme**. Use the **passwd** command from the D20MX SHELL prompt to change the default password to a strong password as soon as possible after downloading the configuration. Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for details on how to configure local user accounts and change the password of a user.

Default user

The default configurations for the D20MX come with one default user account with:

- username: **admin**
- password: **changeme**

Replace this account or change the password for this account as soon as possible. Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for details on how to modify user accounts and how to change the password of a user.

Recovery mode users

When the configuration is defaulted due to a corrupt header or if certain configuration errors exist, the local user accounts becomes unusable. Rather than block access in such scenarios, the D20MX enables a set of recovery mode users to allow you to recover the system (see Table 19). The D20MX only allows someone to login with a recovery mode user over the front RS232 port. The D20MX does not allow someone to login over SSH or SFTP with a recovery mode user. The D20MX disables recovery mode users once a valid configuration is synchronized to the D20MX.

Table 19: Recovery mode usernames and passwords

username	password
westronic	rd
harris	rd
supervisor	rtu

Recovery mode users are granted Read/Write level access to the SHELL.

The recovery mode users are enabled if any of the errors shown in Table 20 are seen on a serial terminal connected to the front RS232 port of a D20MX. Correct the error as described in the *Remedy* column.

Table 20: Errors that indicate recovery mode users are active

Error Message	Remedy

`Error: B014USER table missing or no records.`
`Login with default user and download a config with valid B014USER table.`
`Entering debug mode.`
	Open the D20MX configuration in SGConfig. Ensure the B014USER table in the WESMAINT II+ application (B014-1N) is enabled. Then, synch the configuration to the D20MX.

`Error: B014USER contains records with blank usernames.`
`Login with default user and download a config with valid B014USER table.`
`Entering debug mode.`
	Open the D20MX configuration in SGConfig. Ensure the B014USER table in the WESMAINT II+ application (B014-1N) contains at least one record with a non-blank username. Then, synch the configuration to the D20MX.

`Configuration has been defaulted. Entering debug mode.`	Synch a configuration to the D20MX.

Download image files to the D20MX

When to download

Instances where you may need to download an operating system or application image file to your D20MX:

- When a new version of the operating system or application image has been released.
- If the D20MX has performed self-diagnostics and determined that the application image file is either missing or corrupted.
- After maintenance or replacement work that has deleted the application file.

Prerequisites for image download

The following items must be available before an application or operating system image file can be loaded into a D20MX over a serial or network link:

- Windows PC with SGConfig version 7 and higher software.
- The application firmware file, preferably located on a local hard drive.

  This file will be named: appl.out.
- Optionally, the operating system image file, preferably located on a local hard drive.

  This file will be named: vxWorks.
- A NULL modem cable (GE Energy part number 977-0529) connecting the RS-232 connector on the front panel of the D20MX to the serial communications port of a PC or terminal.
- The D20MX module must be installed into a D20 chassis, ready to power-up.

Prerequisite for image download over a serial link

The following item must be available before an application or operating system image file can be loaded into a D20MX over a serial link:

- A NULL modem cable (GE Energy part number 977-0529) connecting the RS-232 connector on the front panel of the D20MX to the serial communications port of a PC or terminal.

Prerequisite for image download over a network link

The following item must be available before an application firmware file can be loaded into a D20MX over the network:

- An Ethernet switch and appropriate Ethernet patch cables to connect your PC's Network Adapter and the D20MX's Ethernet port 1 to the switch.

- The D20MX contains a configuration file with LAN enabled and an IP address that matches the one configured in SGConfig.

Download software over a serial connection

To download software to the D20MX:

1. Set up Tera Term on a PC. See section: "Set up Tera Term on a PC" on page 62.
2. Download application image file to the D20MX over a serial connection. See section: "Download image files to the D20MX over a serial link" on page 63.

   This comprises:

   – Application files

   – Operating system files (optional)

Set up Tera Term on a PC

To set up the Tera Term on a PC:

1. Connect a NULL modem cable (GE Energy part number 977-0529) from the RS-232 connector on the front panel of the D20MX to the serial communications port of the PC or terminal.
2. Start SGConfig.

   Result: The Welcome to SGConfig screen appears.
3. Open a project containing a D20MX device.

   Result: The project's Main Page appears.
4. Click on a D20MX device.

   Result: The ribbon changes to include the Communications group.
5. Click **Communications** ribbon group > **Connect** drop-down list > **Tera Term**.

   Result: Tera Term: New connection dialog appears
6. Click **Serial** and select the communications port on your PC from the **Port** drop-down list.
7. Click **OK**.

   Result: Tera Term: New connection dialog closes

   Result: The Tera Term VT window appears
8. Select **Setup** > **Serial port...**

   Result: Tera Term: Serial port setup dialog appears
9. Verify (or set) terminal communication settings as follows:

Setting	Value
Port:	COM1 or COM2, or as required by the computer you are using.
Baud Rate	19200 bps
Data	8 bit
Parity	none
Stop	1 bit
Flow Control	Xon/Xoff
Transmit delay	0 msec/char; 0 msec/line

10. Click **OK**.

    Result: The Tera Term settings are now configured.

Download image files to the D20MX over a serial link

To download application and operating system image files to a D20MX module:

1. Restart the D20MX.

   Result: The startup messages appear.

2. When the message "Press Ctrl-E to enter debug mode..." appears, press **Ctrl-E** within 5 seconds.

   Result: The login dialog appears.

3. Log in:

   – For **User**: type a username that has Maintenance or Read/Write Access and press **Enter**,

   – For **Password**: type the password and press **Enter**.

   Result: The D20M> prompt appears.

4. Optional: Speed-up communications to shorten download time.

   Type **Baud 115200** and press **Enter**.

   Note: Select 57600 or 38400 if communications errors have occurred previously. Such errors can occur due to the presence of ambient EMI, a long cable length, a PC with communication limitations due to CPU speed or when using some serial to USB adapters.

   Result: The D20MX is now communicating at 115,200 baud.

   4.1. Select **Setup** > **Serial port...**

   Result: Tera Term: Serial port setup dialog appears.

   4.2. Select **115,200** from the **Baud Rate** drop-down list.

   4.3. Click **OK**.

   Result: Tera Term main window appears and is communicating at 115,200 baud.

5. Download the application image file:

   5.1. Press **Enter** to verify that communication is active.

   Result: The D20M> prompt appears if the connection is active.

   5.2. Type **rz** and press **Enter** to put the D20MX into the state where it is ready to receive the downloadable code file

   5.3. Click **File** > **Transfer** > **ZMODEM** > **Send** from menu bar

   Result: A dialog box opens, prompting you to locate the appl.out file that you wish to download.

   5.4. Select the correct file, and click Open to start the transfer

   NOTE

   Do not press any keys on keyboard and do not move the Tera Term window during download.

   Result: The file transfer may take from less than 10 to over 30 minutes, depending on communication speed selected.
   When complete, the D20M> prompt appears.

6. Optional: Download the operating system image file

   6.1. Press **Enter** to verify that communication is active.

   Result: The D20M> prompt will return if connection is active

   6.2. Type **rz** and press **Enter** to put the D20MX into the state where it is ready to receive the downloadable code file.

   6.3. Click **File** > **Transfer** > **Send** from menu bar.

   Result: A dialog box appears, prompting you to locate the vxWorks file that you wish to download.

   6.4. Select the correct file, and click **Open** to start the transfer

NOTE

Do not press any keys on keyboard and do not move the Tera Term window during download.

Result: The file transfer may take from less than 10 to over 30 minutes, depending on communication speed selected.
When complete, the D20M> prompt appears.

7. Type **cf** to copy the image files to flash.

   Result: The copy may take a few minutes to complete. When complete, the D20M> prompt appears.
8. Type **el /r** to ensure that log is clear.
9. Type **boot** to restart device.

   Result: The image file load is completed.

   The flash memory of the D20MX now has the new application and optional operating system image file loaded.

Configuration File Download

You can use standard SGConfig procedures to download a configuration file over the serial port.

Download software over a network connection

Procedure

To download application image file and optional operating system image file to the D20MX over a network connection:

1. Connect Ethernet port 1 of the D20MX to the Ethernet switch using the appropriate Ethernet patch cable.

   Connect the PC's network adapter to the Ethernet switch using the appropriate Ethernet patch cable.
2. Start SGConfig.

   Result: The Welcome to SGConfig screen appears.
3. Open a project containing the target D20MX device.

   Result: The project's Main Page appears.
4. Click on the D20MX device.

   Result: The Communications group appears in the ribbon.
5. Click the ribbon **Communications** group > **Options**.

   Result: D2x Device Communication Options dialog appears
6. Click **Interface** tab > Connection Type > **iSCS LAN** and select the Preferred LAN you wish to use, either **LAN A** or **LAN B**. This will most likely be **LAN A**.
7. Click **OK**.

   Result: D2x Device Communication Options dialog closes.
8. Click **Edit** ribbon group > **Properties**.

   Result: A Dialog appears, prompting you to make a backup copy.
9. Click **Yes** or **No** depending on whether you want to make an internal backup copy.

   If you click **Yes**, a dialog appears indicating that the device is being backed up. Finally, a dialog appears indicating that the device has been backed up.
10. Click **OK**.

    Result: The D20 Device Wizard appears
11. Click **Next**.

    Result: The Project LAN properties appear.

12. Click **Next**.

    Result: The hardware and other properties appear for the device.
13. Click **Processor** tab > **Code Image** sub-tab.
14. Click the button with the ellipsis (**...**).

    Result: The Select Flash image file dialog appears.
15. Navigate to the folder containing the appl.out file and optional vxWorks file.
16. Select the **appl.out** file and click **Open**.

    Result: The full pathname of the appl.out file appears in the Flash Image File box.
17. Click **Next**.
18. Click **Finish**.

    Result: The project's Main Page appears with the D20MX device selected.
19. Click the ribbon **Communications** group > **Firmware transfer**.

    Result: Warning message appears and confirmation to continue is requested.
20. Acknowledge the warning and click **Yes** to continue or **No** to abort the operation.

    Result: If Yes is selected, a Login dialog appears. If No is selected, the operation is aborted.
21. Enter a **User Name** that has Maintenance or Read/Write access. Enter the associated **Password**.

    Result: The firmware transfer takes place. A dialog indicating the transfer and reboot is taking place is presented. The unit is rebooted once the transfer finishes. Once the reboot completes, the dialog disappears. The whole operation can take up to 8 minutes.

    The flash memory of the D20MX now has the new application and optional operating system image file loaded.

Configuration file download

You can use standard SGConfig procedures to download a configuration file over the network.

SGConfig firmware options

The D20MX is available with two different SGConfig firmware options:

- SAN0001
  The SAN0001 option contains the latest versions of all applications and should be used in all new configurations.
- SAN0002
  The SAN0002 option contains previous versions of Mailbox DTA and DNP V3.00 DPA. This allows for seamless migration from older D20ME firmware.

The actual firmware on the D20MX supports both SGConfig firmware options. Accordingly, there is no need to perform a firmware transfer to change the D20MX firmware when changing between SGConfig firmware options.

See section: “D20MX applications” on page 16 for a list of the automation applications provided with these two firmware options.

The D20MX firmware's ability to support multiple SGConfig firmware options is being provided in release 1.0, but is not expected to be continued in future releases.

The SANnnnn firmware options are made available within SAGnnnn files. A SAGnnnn file comprises a:

- Default Configuration, and a
- SANnnnn firmware option

Update to the SAN0001 firmware option

If the D20MX was ordered with the SAN0002 SGConfig firmware option and migration from older firmware is not required or the latest application versions are required, the following procedure can be followed to update your D20MX configuration to the SGConfig SAN0001 firmware option.

Procedure

To update the D20MX configuration to the SGConfig SAN0001 firmware option:

1. Start SGConfig,

   Result: The Welcome to SGConfig screen appears.
2. Open a project (e.g., TEST_PROJ).
3. Import the SAG0001 firmware option.

   If the SAG0001 firmware option has already been imported, go to step 4 to open the firmware option:

   3.1. Click **GE** > **Archive** > **Project** > **Restore**.
   Result: The Restore Project Details window appears.

   3.2. Click **...** .
   Result: The Choose a File window appears.

   3.3. Locate this configurations in project archives named SAG0001-00.7zip in the GE Digital Energy D20MX Documentation CD (part number 588-0075/00).

   Result: SAG0001 is displayed in the Restore Project Details window. The name can be changed if desired.

   3.4. Click **OK**.

   Result: On completion a pop-up message appears: Project 'SAG0001' has been restored.

   3.5. Click **OK**.
4. Open SAG0001: click **GE** > **Recent Projects** > select **SAG0001**.
5. Transfer the SAN0001 firmware option to the Project:

   5.1. Click the ribbon **Configure** group > **Miscellaneous** > **Firmware Library**.
   Result: The Firmware Library window appears.

   5.2. Click **Copy**.

   5.3. Select menu item **Copy To**.

   5.4. Select the Project you want to copy the configuration to (e.g., TEST_PROJ) from the drop-down menu.

   5.5. Click **OK**.

   5.6. Click **Close**.
6. Close SAG0001:

   6.1. Click **GE** > **Close Project**.
   Result: The Close Project window appears.

   6.2. Select: **SAG0001**.

   6.3. Click **OK**.

7. Make a backup copy of the original D20 device configuration:
   7.1. Click the **Project: TEST_PROJ** tab.
   7.2. Click the D20 device.
   7.3. Click the ribbon **Configure** group > **Edit** > **Copy**.
   7.4. Click a blank area on the page onto which the copy is to be placed.
   7.5. Click the ribbon **Configure** group > **Edit** > **Paste**.
   Result: The Copying device window appears.
   Result: Once completed a new device named COPY_OF_<original device name> appears.
8. Apply the new (SAN0001) firmware to the Project:
   8.1. Click the **Project: TEST_PROJ** tab.
   8.2. Click the D20 device.
   8.3. Click the ribbon **Configure** group > **Edit** > **Properties**.
   Result: A Warning prompts you to save an internal backup copy.
   8.4. Click: **Yes** to create a backup, or **No** to not create a backup.
   Result: The D20 Device Wizard Basic Settings window appears.
   8.5. Click **Next >**.
   Result: The D20 Device Wizard - Define the LAN properties for this project window appears.
   8.6. Click **Next >**.
   Result: The D20 Device Wizard - Define hardware and other properties window appears.
   8.7. Select: **Processor** tab > **Firmware** tab.
   8.8. From the Firmware Type click **Select**.
   Result: The Select a Firmware Type window appears with SAN0001 and previous firmware on the device shown.
   8.9. Click **SAN0001**.
   8.10. Click **OK**.
   Result: The Select a Firmware Type window closes.
   8.11. Click **Next >** on the D20 Device Wizard - Define hardware and other properties for this device window.
   Result: Applications are updated and SAN0001 firmware is applied.
   8.12. Click **Finish**.
9. Review Warnings
   9.1. Select the **Project: TEST_PROJ** tab
   9.2. Click the D20 device.
   9.3. Click the ribbon **Configure** group > **Draw** > select **Output Window**.
   Result: The Device Log window appears.
   9.4. Review all warnings and make corrections as needed, reviewing the backup copy to retrieve values that may have been replaced with default values during the upgrade.
10. Generate Project,
   10.1. Select the **Project: TEST_PROJ** tab.
   10.2. Click: the D20 device.
   10.3. Click the ribbon **Configure** group > **Generate**.
   10.4. Confirm that there are zero errors in the Device Log; any Warnings are acceptable.

11. Setup LAN Communication
    11.1. Select the **Project: TEST_PROJ** tab.
    11.2. Click: the D20 device.
    11.3. Click the ribbon **Configure** group > **Communications** > **Options**.
    Result: The Device Communication Options widow appears.
    11.4. Click **Interface** tab > **Connection Type**.
    11.5. Select **iSCS LAN**.
    11.6. Click **OK**.
12. Transfer the new configuration files to the D20MX:
    12.1. Select the **Project: TEST_PROJ** tab.
    12.2. Click: the D20 device.
    12.3. Click the ribbon **Configure** group > **Sync To**.
    Result: A Warning message prompts you to NOT interrupt the operation and confirms the device is connected.
    12.4. Click **Yes** to continue.
    Result: The Login window appears, prompting for User Name and Password (use your configured login credentials, default are westronic / changeme)
    Result: A Warning message indicates that the public key has CHANGED; this appears when you are connecting to the device for the first time.
    12.5. Click **Yes** to continue.
    Result: The Transferring configuration window appears showing the transfer status.
    Result: When the transfer is complete the Device configuration transferred successfully message appears.
    12.6. Click **OK**.

Transfer D20/D200 configurations to the D20MX

Use this information to transfer existing D20 and D200 device configurations to the D20MX.

The word “transfer” is used within the context of this guide to mean that the device configuration files are moved and modified, in order to work properly on a D20 with a D20MX processor.

If you are transferring a D20 device configuration, follow the steps in section: “Transferring a D20 configuration to the D20MX” on page 69.

If you are transferring a D200 device configuration, follow the steps in the following sections:

- Section: “Transferring a D200 configuration to the D20MX” on page 74
- Section: “Transferring a D20 configuration to the D20MX” on page 69

Transferring a D20 configuration to the D20MX

Prerequisites

Before you can transfer a D20 device configuration, the following components must be present:

- SGConfig™ 7.00 or higher installed on the configuration computer.
- The D20MX Documentation CD (part number 588-0075/00) installed in a CD/DVD drive of the configuration computer.
- D20 Configuration has been migrated to SGConfig™ with the Migration Wizard (Refer to the Migration Wizard screencast).
- To save time, you may upgrade the firmware definition of your D20 or D200 Configuration to SAN0001 or SAN0002 in ConfigPro. If you choose to take this option, follow the instructions provided in Section: "Updating D20/D200 configurations to use the D20MX firmware definition with ConfigPro" on page 75.

Procedure

To transfer a D20 or D200 device configuration to the D20MX:

1. Start SGConfig.2

   Result: The Welcome to SGConfig screen appears.
2. Choose the D20MX Factory Default Configuration file, SAG0001-00.7zip or SAG0002-00.7zip. based on the following criteria:
   - If transferring a configuration containing B009 versions greater than 310 and B021 versions greater than 912 use the file SAG0001-00.7zip
   - If transferring a configuration containing B009 versions less than or equal to 310 and B021 versions less than or equal to 912, use the file SAG0002-00.7zip.
3. If the SAG0001 or SAG0002 firmware option has already been imported, go to step 4 to open the firmware option. Otherwise perform these steps:
   3.1. Click **GE** button > **Archive** > **Project** > **Restore**.2

   Result: The Restore Project Details window appears.

   3.2. Click **...** .

   Result: The Choose a File window appears.

   3.3. Navigate to the DVD/CD drive > Configuration Files > SGConfig.

   Result: The two files SAG0001-00.zip and SAG0002-00.zip appear in the dialog.

   3.4. Select the appropriate file based on your decision in step 2.

   3.5. Click **OK**.

   Result: On completion a pop-up message appears (e.g. Project 'SAG0001' has been restored).

   3.6. Click **OK**.
4. Open the D20MX Factory Default Configuration SAG0001 or SAG0002: click **GE** > **Recent Projects** > select **SAG0001** or **SAG0002**.
5. Copy the firmware definition from the factory default configuration to the project containing the D20 configuration (if you had opted to upgrade the firmware in ConfigPro, then this step is not necessary):
   5.1. Click the ribbon **Configure** group > **Miscellaneous** > **Firmware Library**.

   Result: The Firmware Library window appears with the firmware definition selected.

   5.2. Click **Copy**.

   Result: The Firmware Information window appears.

   5.3. Set the **Project Name** in the Copy To region to the project containing the D20 configuration.

5.4. Click **OK**.
Result: The Firmware Information window closes.
5.5. Click **Close**.
Result: The Firmware Library window closes.

6. Export the RADIUS roles from the default configuration:
6.1. Double-click the D20 device named FAC_DEF.
Result: The Application List popup appears.
6.2. Double-click the WESMAINT II+ application.
Result: The WESMAINT II+ table icon set appears.
6.3. Right-click the RADIUS Role Table icon and select **Export**
Result: The Export Options dialog appears.
6.4. Click on the button containing an ellipsis (...) under the Place export files in area.
Result: The Choose a folder dialog appears.
6.5. Browse to a folder (e.g. your Desktop) and click **OK**, **OK**, and **Cancel**.
Result: The main page of the project appears.
7. Export the IP Redundancy Monitor point descriptors from the default configuration:
7.1. Double-click the D20 device named FAC_DEF
Result: The Application List popup appears.
7.2. Double-click the System Point Database application.
Result: The System Point Database Properties dialog appears.
7.3. Select IP Redundancy Monitor and click **Descriptors**.
Result: The Point Descriptors dialog appears.
7.4. Click on the **Export** button.
Result: The Export Point Descriptors dialog appears.
7.5. Click **OK**.
Result: The Browse For Folder dialog appears.
7.6. Browse to a folder and click **OK, OK** and **OK.**
Result: The main page of the project appears.
8. Close the D20MX Factory Default Configuration (i.e. SAG0001 or SAG0002):
8.1. Click **GE** > **Close Project**.
Result: The Close Project window appears.
8.2. Select: **SAG0001** or **SAG0002**.
8.3. Click **OK**.
9. Open the SGConfig project containing the D20 device.:
9.1. Click the **GE** button.
9.2. Click the required SGConfig project in the **Recent Projects** list or select the **Open Project** menu item.
10. Make a backup copy of the original D20 device configuration:
10.1. Click the **Project** tab of the original D20 device configuration**.**
10.2. Click the D20 device.
10.3. Click the ribbon **Configure** group > **Edit** > **Copy**.
10.4. Click a blank area on the page onto which the copy is to be placed.
10.5. Click the ribbon **Configure** group > **Edit** > **Paste**.
Result: The Copying device window appears.
Result: Once completed a new device named COPY_OF_<original device name> appears.

11. Select a D20MX processor from the D20 Device Wizard:
    11.1. Click the **Project** tab of the original D20 device configuration**.**
    11.2. Click the D20 device.
    11.3. Click the ribbon **Configure** group > **Edit** > **Properties**.Result: A Warning prompts you to save an internal backup copy.
    11.4. Click **Yes** to create a backup, or **No** to not create a backup.
    Result: The D20 Device Wizard Basic Settings window appears.
    11.5. Click **Next** until the Processor tab appears.
    11.6. Click the **Processor** tab > **General** sub-tab.
    11.7. From the Part Number field, click **Select**.
    Result: The Select a Processor Card window appears.
    11.8. Select one of the three D20MX processor type part numbers (526-3001, 526-3003 or 526-3005).
    11.9. Click **Next**, **Next**, **Firmware** tab, **Select**.
    11.10. Select either **SAN0001 / 000** or **SAN0002 / 000.** If you had opted to upgrade the firmware in ConfigPro, then this step is not necessary.
    11.11. Click **OK**.
    11.12. Click **Next**, **Finish**.
    Result: The D20 Device Wizard closes.
12. Review warnings:
    12.1. Click the **Project** tab of the original D20 device configuration.
    12.2. Click the D20 device.
    12.3. Click the ribbon **Configure** group > **Draw** > select **Output Window**.
    Result: The Device Log window appears.
    12.4. Review all warnings and make corrections as needed, reviewing the backup copy to retrieve values that may have been replaced with default values during the upgrade.
13. Ensure the BOOTP client is disabled:
    13.1. Click the **Project** tab of the original D20 device configuration.
    13.2. Click the D20 device.
    13.3. Click the ribbon **Edit** group > **Properties**.
    Result: A Warning prompts you to save an internal backup copy.
    13.4. Click **Yes** to create a backup, or **No** to not create a backup.
    Result: The D20 Device Wizard appears.
    13.5. Click **Next** until the Processor tab appears.
    13.6. Click the **LAN Settings** tab > **General** sub-tab.
    13.7. From the BOOTP Settings frame, ensure **Not Used** is checked.
    13.8. Click **Next** and **Finish**.
    Result: The D20 Device Wizard closes.
14. Disable new applications not in the transferred D20/D200 firmware:
    14.1. Click the **Project** tab of the original D20 device configuration.
    14.2. Double-click the D20 device.
    Result: The Application List popup appears.
    14.3. Control click on applications not in the transferred D20/D200 firmware.
    Result: The application rows are highlighted.

14.4. Click on **Disable Application(s)**.
Result: A warning dialog appears.

14.5. Click **Yes**.
Result: The warning dialog and the Application list popup disappear.

15. Import the RADIUS roles from the D20MX default configuration into the D20 device:

15.1. Double-click the D20 device.
Result: The Application List popup appears.

15.2. Double-click the WESMAINT II+ application.
Result: The WESMAINT II+ table icon set appears.

15.3. Right-click the RADIUS Role Table icon and select **Import**.
Result: The Select source directory dialog appears.

15.4. Browse to the folder containing the exported RADIUS Role Table, select the file named **B014RADR**, and click **Open**.
Result: The WESMAINT II+ table icon set re-appears.

15.5. Double-click the RADIUS Role Table icon.
Result: The RADIUS Role Table editor appears.

15.6. Compare the first two columns of the RADIUS Role Table to the following figure to confirm that the import was successful.



Role	Role ID	Role Name	Time Format	Date Separator	Date Format
1	0	Observer	24 hr	Hyphen	YY MM DD
2	1	Engineer	24 hr	Hyphen	YY MM DD
3	2	Administrator	24 hr	Hyphen	YY MM DD
4	3	Operator	24 hr	Hyphen	YY MM DD

15.7. Click **OK**.
Result: The WESMAINT II+ table editor closes.

16. Import the IP Redundancy Monitor point descriptors:

16.1. Click the **Project** tab of the original D20 device configuration.

16.2. Double-click the D20 device.
Result: The Application List popup appears.

16.3. Double-click the System Point Database application.
Result: The System Point Database Properties dialog appears.

16.4. Select IP Redundancy Monitor and click **Descriptors**.
Result: The Point Descriptors dialog appears.

16.5. Click on the **Import** button.
Result: The Import Point Descriptors dialog appears.

16.6. Click **OK**.

Result: The Browse For Folder dialog appears.

16.7. Browse for the folder containing the exported IP Redundancy Monitor point descriptions and click **OK.**

Result: The Point Descriptors dialog appears.

16.8. Confirm the point descriptors are as shown in the following figure.



16.9. Click **OK** and **OK.**

Result: The main project window appears.

17. If the site is not using a modem attached to COM0, change the baud rate of COM0 to 19.2K:

17.1. Click the **Project** tab of the original D20 device configuration.

17.2. Double-click the D20 device.

Result: The Application List popup appears.

17.3. Double-click the WESMAINT II+ application.

Result: The WESMAINT II+ table icon set appears.

17.4. Double-click the Port Configuration table icon.

Result: The Port Configuration table editor appears.

17.5. Change the Baud Rate of COM0 to 19.2k and click OK

Result: The WESMAINT II+ table editor closes.

18. Optionally, update the RADIUS and SYSLOG settings in B014-1N (WESMAINT II+):

18.1. Click the **Project** tab of the original D20 device configuration.

18.2. Double-click the D20 device.

Result: The Application List popup appears.

18.3. Double-click the WESMAINT II+ application.

Result: The WESMAINT II+ table icon set appears.

18.4. Update the new tables: Remote RADIUS Servers Table, Remote Syslog Servers Table, TLS Auth Info Table, TLS CA Info Table, First PEM File Table, Second PEM File Table and Login Warning Banner Table, referring to the B014-1NCG WESMAINT II+ configuration guide.

19. Generate the iSCS Configuration for the Project:

19.1. Click the **Project** tab of the original D20 device configuration.

19.2. Click: the D20 device.

19.3. Click the ribbon **Configure** group > **iSCS** > **Generate**.

19.4. Confirm that there are zero errors in the Device Log; any Warnings are acceptable.

20. Setup LAN Communication:
    20.1. Click the **Project** tab of the original D20 device configuration
    20.2. Click: the D20 device.
    20.3. Click the ribbon **Configure** group > **Communications** > **Options**.
    Result: The Device Communication Options widow appears.
    20.4. Click **Interface** tab > **Connection Type**.
    20.5. Select **iSCS LAN**.
    20.6. Click **OK**.
21. Transfer the new configuration files to the D20MX:
    21.1. Click the **Project** tab of the original D20 device configuration
    21.2. Click: the D20 device. 12.3.
    21.3. Click the ribbon **Configure** group > **Sync To**.
    Result: A Warning message prompts you to NOT interrupt the operation and confirms the device is connected.
    21.4. Click **Yes** to continue.
    Result: The Login window appears, prompting for User Name and Password (use your configured login credentials, default are westronic / changeme)
    Result: A Warning message indicates that the public key has CHANGED; this appears when you are connecting to the device for the first time.
    21.5. Click **Yes** to continue.
    Result: The Transferring configuration window appears showing the transfer status.
    Result: When the transfer is complete the Device configuration transferred successfully message appears.
    21.6. Click **OK**.
22. Note that all users that existed in the transferred D20/D200 configuration will now have a default password of "changeme". Change these passwords using the passwd command in the D20MX Shell. Refer to the WESMAINT Configuration Guide B014-0NCG for details of this command.

Transferring a D200 configuration to the D20MX

Prerequisites

Before you can transfer a D200 device configuration, the following components must be present:

- SGConfig™ 7.00 or higher installed on the configuration computer
- D200 Configuration has been migrated to SGConfig™ with the Migration Wizard (Refer to the Migration Wizard screencast).

Procedure

NOTICE

Migrating a multi-processor D200 will only transfer the application configurations on the first processor.

This is manually resolved by moving applications from other processors to the first processor using the SGConfig device editing functions BEFORE converting the device to a D20 in the instructions below.

Single and multi-processor D200 devices must first be changed into D20 devices before the D20MX processor card option can be selected. To change a D200 device into a D20 device perform the following steps:

1. Start SGConfig.
   Result: The Welcome to SGConfig screen appears.
2. Open a project containing the D200 device you want to transfer to a D20MX:
   2.1. Click the **GE** button.
   2.2. Click the required SGConfig project in the **Recent Projects** list or select the **Open Project** menu item.
3. Make a backup copy of the original D200 device configuration:
   3.1. Click the **Project** tab of the original D200 device configuration**.**
   3.2. Click the D200 device.
   3.3. Click the ribbon **Configure** group > **Edit** > **Copy**.
   3.4. Click a blank area on the page onto which the copy is to be placed.
   3.5. Click the ribbon **Configure** group > **Edit** > **Paste**.
   Result: The Copying device window appears
   Result: Once completed a new device named COPY_OF_<original device name> appears.
4. Click the ribbon **Configuration** group > **Change Type**.
   Result: The Change Device window appears.
5. Select type **D20** and click **OK**.
6. Follow the steps in section: Transferring a D20 configuration to the D20MX.

Updating D20/D200 configurations to use the D20MX firmware definition with ConfigPro

Use this information to update the firmware definition of an existing D20 and D200 device configuration to the D20MX firmware definition. The result is a device archive that you can migrate into SGConfig for the purpose of transferring the D20/D200 configuration to the D20MX. The remaining steps of the transfer are described in “Transfer D20/D200 configurations to the D20MX” on page 68.

If you are updating a D20 device configuration, follow the steps in section: Updating a D20 configuration to use the D20MX.

If you are transferring a D200 device configuration, follow the steps in the following sections:

- “Updating a D200 configuration to use the D20MX firmware definition with ConfigPro” on page 78
- “Updating a D20 configuration to use the D20MX firmware definition with ConfigPro” on page 76

Updating a D20 configuration to use the D20MX firmware definition with ConfigPro

Prerequisites

Before you can update the firmware definition of a D20 device configuration, the following components must be present:

- ConfigPro 5.03 or higher installed on the configuration computer.
- The D20MX Documentation CD (part number 588-0075/00) installed in a CD/DVD drive of the configuration computer.

Procedure

To update a D20 or D200 device configuration to the D20MX:

1. Start Config Pro 5.03 or higher.

   Result: The main window of ConfigPro appears with the tree view of the project directory on the left.
2. Choose the D20MX Factory Default Configuration file, 10730-00.zip or 10731-00.zip. based on the following criteria:
   - If transferring a configuration containing B009 versions greater than 310 and B021 versions greater than 912 use the file 10730-00.zip
   - If transferring a configuration containing B009 versions less than or equal to 310 and B021 versions less than or equal to 912, use the file 10731-00.zip.
3. Select from the menu bar **Project** > **Archive Project** > **Restore**.

   Result: The Restore Project from ZIP File dialog appears
4. Under the Select Source Project ZIP File area, click the **document** icon.

   Result: The Select a Project ZIP file to Restore dialog appears.
5. Navigate to the DVD/CD drive > Configuration Files > ConfigPro.

   Result: The two files 10730-00.zip and 10731-00.zip appear in the dialog.
6. Select the appropriate file based on your decision made in the second step and click the **Select** button.

   Result: The Restore Project from ZIP File dialog appears with the selected file showing under the Select Source Project ZIP File area.
7. Under the "Restore To" area, click the **folder** icon.

   Result: The Select the Destination Project Directory dialog appears.
8. Navigate to your ConfigPro project folder on a hard drive of the configuration computer. The project folder is typically named *C:\WESDATA*.

   Result: The contents of the project folder are displayed, and the file named *WPL400.DB* is selected.
9. Click the **Select** button.

   Result: The Restore Project from ZIP File dialog reappears with the Project Directory set to the folder you selected in the previous step.
10. Change the Project Name if desired and click **OK**.

    Result: The main window of ConfigPro appears with the tree view of the project directory on the left. The new D20MX factory default project appears in the tree view.
11. Double-click on the D20MX factory default project.

    Result: The Main Page of the D20MX factory default project appears with the FAC_DEF device placed on the page.
12. Double-click the FAC_DEF device.

    Result: The Missing Applications! dialog appears.

13. Click the **Install** button.

    Result: The Select the Source Application Definition Directory dialog appears.

14. Navigate to the DVD/CD drive > **DEFNS** > **APPLDEF**.

    Result: The contents of the APPLDEF folder is displayed with the file *DAL100.DB* selected.

15. Click **Select**.

    Result: Messages are displayed about the application definitions being extracted to the configuration computer, and finally the Data Collection Applications of the FAC_DEF device appear.

16. Close the device configuration by clicking on the **door** icon.

    Result: The Main Page of the D20MX factory default project appears with the FAC_DEF device appearing on the page.

17. Click from the menu bar, **Device** > **Firmware**.

    Result: The Firmware Library dialog appears. Depending on which factory default project you chose in the second step, either SAN0001 or SAN0002 will appear.

18. Click **Copy**.

    Result: The Firmware Information dialog appears.

19. In the "Copy To" area select the Project Directory and Project Name of the project you want to transfer to the D20MX.

    Result: The "Copy To" area contains the Project Directory and Project Name of the project you want to transfer to the D20MX.

20. Click **OK**, **Close** and the **door** icon

    Result: The main window of ConfigPro appears with the tree view of the project directory on the left.

21. Make a backup copy of your project.

    21.1. Select from the menu bar, **Project** > **Copy Project**.

    Result: The Copy Project dialog appears.

    21.2. In the "From" area, navigate to the folder and select the project you want to transfer to the D20MX.

    21.3. In the "To" area, enter a new unique name for the project.

    21.4. Click **OK**.

    Result: The main window of ConfigPro appears with the tree view of the project directory on the left.

22. On the tree view displayed to the left, navigate to the copied project and double-click on the project name.

    Result: The main window of the copied project appears.

23. Right-click on the D20 device you want to transfer and select **Properties**.

    Result: The D20 Device Properties window appears.

24. Click the **Processor** tab and the **Firmware** tab. Then click **Select**.

    Result: The Select a Firmware Type dialog appears. Depending on which factory default project you chose in the second step, either SAN0001 or SAN0002 will appear.

25. Select whichever of SAN0001 or SAN0002 appears and click **OK** and **OK**.

    Result: A confirmation dialog appears asking if you want to make a backup copy now.

26. Click No because you have already made a backup.

    Result: Messages will appear indicating the upgrade is in progress. Messages appear in the Device Log indicating the results of the upgrade. The D20 device appears with a red dot.

27. Review all warnings and make corrections as needed, reviewing the original copy to retrieve values that may have been replaced with default values during the upgrade
28. Right-click on the device and click **Generate**.

    Result: The device is displayed without a red dot.
29. Right-click on the device and click **Archive** > **Save**.

    Result: The Save Device to ZIP File dialog appears.
30. In the "Save To" area, click the **folder** icon.

    Result: A dialog appears with the title "Select a directory in which to save the project".
31. Navigate to a folder on your PC where you would like to save the device archive and click **Select** and **OK**.
32. Close ConfigPro.
33. Migrate the D20 Device Archive into SGConfig™ using the Migration Wizard (Refer to the Migration Wizard screencast).

Updating a D200 configuration to use the D20MX firmware definition with ConfigPro

Prerequisites

Before you can update the firmware definition of a D200 device configuration, the following components must be present

- ConfigPro 5.03 or higher installed on the configuration computer.
- The D20MX Documentation CD (part number 588-0075/00) installed in a CD/DVD drive of the configuration computer.

Procedure

NOTICE

Migrating a multi-processor D200 will only transfer the application configurations on the first processor.

This is manually resolved by moving applications from other processors to the first processor using the ConfigPro device editing functions BEFORE converting the device to a D20 in the instructions below.

Single and multi-processor D200 devices must first be changed into D20 devices before the D20MX firmware definition can be selected. To change a D200 device into a D20 device perform the following steps:

1. Start ConfigPro 5.03 or higher.

   Result: The main window of ConfigPro appears with the tree view of the project directory on the left.
2. Make a backup copy of the project you want to transfer to the D20MX.
   - 2.1. Select from the menu, **Project** > **Copy Project**.

     Result: The Copy Project dialog appears.
   - 2.2. In the "From" area, navigate to the folder and select the project you want to transfer to the D20MX.
   - 2.3. In the "To" area, enter a new unique name for the project.
   - 2.4. Click **OK**.

     Result: The main window of ConfigPro appears with the tree view of the project directory on the left.
3. On the tree view displayed to the left, navigate to the project and double-click on the project name.

   Result: The main window of the copied project appears

4. Right-click on the D20 device you want to transfer and select **Tools** > **Change**.
   Result: The Change Device window appears.
5. Select type **D20** and click **OK**.
6. Follow the steps in section: "Updating a D20 configuration to use the D20MX firmware definition with ConfigPro" on page 76.

D20MX Processor

Chapter 6: Using the D20MX

The D20MX operation can be monitored and accessed through:

- Operational status LEDs
- LAN port status LEDs
- Fiber optic status port LEDs

Front panel LEDs

Once the D20MX is powered up, the LED indicators on the front panel become active. The indicators provide status information on the operation of the D20MX.

Operational status LEDs

The status LEDs indicate the unit's operational status:

LED Display	Label	Color	Status Description
	**PWR**	Green	**Power** Solid light when 5 V DC power is correctly supplied to the processor board. OFF when 5 V DC is not present.
	**RDY**	Green	**Ready** Flashes when Initialization (boot-up and self-diagnostics) of the D20MX is complete and the unit is ready to process data.

LED Display	Label	Color	Status Description
	**IRIG**	Green	Flashes when an IRIG-B format time synchronization signal has been supplied to the unit and has been used to set the D20 system clock. **Note**: When removing IRIG-B signal, the LED keeps blinking for up to a minute before turning off.
		Green	Normally off; reserved for future expansion.

LAN port status LEDs

The LAN Port Status LEDs provide a visual indication of the status for the Ethernet communication ports on the front of the D20MX.

LED Display	Label	Color	Status Description
	**LINK**	Orange for 1000BASE-T. Green for 10/100BASE-T	**Link 1, Link 2** Solid light when an active device is connected to the Ethernet port.
	**ACT**	Yellow	**Activity 1, Activity 2** Flashes when data is transmitted or received on the channel.

Fiber optic port status LEDs

The fiber optic port status LEDs provide a visual indication of the status for fiber optic ports 1 and 2.

LED Display	Label	Color	Status Description
	**LINK 1** **LINK 2**	Green	**Link 1, Link 2** Solid light when an active device is connected to the fiber optic port.
	**ACT 1** **ACT 2**	Yellow	**Activity 1, Activity 2** Flashes when data is transmitted or received on the channel.

D20MX Processor

Chapter 7: Servicing the D20MX

The D20MX does not require scheduled maintenance.
This chapter describes how to inspect the unit and remove the D20MX processor.

Performing periodic inspection

Periodic inspection is recommended to ensure that:

- The device has sustained no accidental physical damage
- Connectors and cables are intact and firmly attached

Removing the D20MX processor module

The D20MX can be removed from a non-VME (GE part number 500-0305) or VME (GE part number 500-0280) D20 chassis.

NOTICE

1. Ensure that you are sufficiently grounded to prevent ESD damage to the D20MX or other components. See section: "Grounding the D20MX" on page 36.

To remove the D20MX from a D20 chassis

1. Power down the D20 and disconnect the power supply.
2. Disconnect all communication cables from the front panel of the D20MX and the backplane of the D20 chassis.
3. Loosen the front panel retaining screws.
4. Remove the blank plates located above and below the D20MX.
5. Slide the D20MX partially out.
6. For the D20MX Non-VME with Dual 100Base-FX Fiber Optic Card (526-3005LF) only:
   - 6.1. Disconnect the 975-1236 cable (connecting the fiber optic daughter card) from connectors J3 and J4 on the D20MX processor module.
   - 6.2. Loosen the D20MX fiber card front panel retaining screws.
   - 6.3. Carefully slide out the D20MX fiber card partially.

6.4. Remove the 975-1236 cable through the middle slot in the chassis.

6.5. Store the D20MX fiber card in static-protective packaging.

7. Grasp the D20MX by the front handles and slide the processor module all the way out of the D20 chassis.

⚠CAUTION

Allow the D20MX to cool before removing. The heatsink of the D20MX may be extremely hot during and immediately after operation. Use caution when removing the processor module from the chassis to avoid being burned.

8. Store the D20MX in static-protective packaging.

D20MX Processor

Appendix A: Default Role-Based Access Control Model

Configured roles in the D20MX

When you configure the D20MX to use RADIUS, the D20MX must be configured with a set of roles in the B014 RADIUS Roles Table (B014RADR) of the WESMAINT II+ application (Refer to the *B014-1NCG WESMAINT II+ for the D20MX Configuration Guide* for more information). The role is identified by a role ID, which is an integer number provided by the RADIUS server.

The D20MX Default configurations SAG0001 and SAG0002 include a default role-based access control model that meets the general rules shown in Table 21: General Access Control Rules. The specific flags defined in the Application Control field of the RADIUS Roles table are provided in Table 22 through Table 42.

Table 21: General access control rules

Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
Can Change Passwords	Yes	No	No	No
Can Clear the Login Buffer	No	No	No	No
Can Change SCADA Settings	Yes	Yes	No	No
Can Download Firmware	Yes	Yes	No	No
Can Perform Operational Control (e.g. breaker operation)	Yes	Yes	Yes	No
Can View Operational Data	Yes	Yes	Yes	Yes
Can Access Low Level "C" Shell	Yes	No	No	No

Table 22: Shell access level

Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
Access Level	Read/Write	Maintenance	Read Only	Read Only

Table 23: Modify access flags for WESMAINT (Application number: 14)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Time and Date display	Yes	Yes	Yes	No
1	Peripheral Status display	Yes	Yes	Yes	No
2	Peripheral Status Detail display	Yes	Yes	No	No
3	COS Buffer display	Yes	Yes	Yes	No
4	D20 Monitor display	Yes	Yes	Yes	No
5	Digital Inputs display	Yes	Yes	No	No
6	Digital Inputs Detail display	Yes	Yes	Yes	No
7	Digital Outputs display	Yes	Yes	No	No
8	Digital Outputs Detail display	Yes	Yes	Yes	No
9	Analog Inputs display	Yes	Yes	No	No
10	Analog Inputs Detail display	Yes	Yes	Yes	No
11	Analog Outputs display	Yes	Yes	No	No
12	Analog Outputs Detail display	Yes	Yes	Yes	No
13	Transition Counter display	Yes	Yes	No	No
14	Transition Counter Detailed display	Yes	Yes	Yes	No
15	SOE Buffer display	Yes	Yes	Yes	No
16	Login Buffer display	Yes	No	No	No
17	Database Synch display	Yes	Yes	Yes	No
18	Switch-over display	Yes	Yes	Yes	No
19	System Status display	Yes	Yes	No	No
20	Communication Status display	Yes	Yes	No	No
21	Complex Object display	Yes	Yes	No	No
22	Complex Object Detail display	Yes	Yes	No	No
23	Generic Data display	Yes	Yes	No	No
24	Generic Data Detail display	Yes	Yes	No	No
25 - 31	Not used.	Yes	Yes	No	No

Table 24: Read access flags for WESMAINT (Application number: 14)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Time and Date display	Yes	Yes	Yes	Yes
1	Peripheral Status display	Yes	Yes	Yes	Yes
2	Peripheral Status Detail display	Yes	Yes	Yes	Yes
3	COS Buffer display	Yes	Yes	Yes	Yes
4	D20 Monitor display	Yes	Yes	Yes	Yes
5	Digital Inputs display	Yes	Yes	Yes	Yes
6	Digital Inputs Detail display	Yes	Yes	Yes	No
7	Digital Outputs display	Yes	Yes	Yes	Yes
8	Digital Outputs Detail display	Yes	Yes	Yes	No
9	Analog Inputs display	Yes	Yes	Yes	Yes
10	Analog Inputs Detail display	Yes	Yes	Yes	No
11	Analog Outputs display	Yes	Yes	Yes	Yes
12	Analog Outputs Detail display	Yes	Yes	Yes	No
13	Transition Counter display	Yes	Yes	Yes	Yes
14	Transition Counter Detailed display	Yes	Yes	Yes	No

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
15	SOE Buffer display	Yes	Yes	Yes	Yes
16	Login Buffer display	Yes	Yes	No	No
17	Database Synch display	Yes	Yes	Yes	No
18	Switch-over display	Yes	Yes	Yes	No
19	System Status display	Yes	Yes	Yes	Yes
20	Communication Status display	Yes	Yes	Yes	Yes
21	Complex Object display	Yes	Yes	No	No
22	Complex Object Detail display	Yes	Yes	No	No
23	Generic Data display	Yes	Yes	No	No
24	Generic Data Detail display	Yes	Yes	No	No
25-31	Not used.	Yes	Yes	No	No

Table 25: Modify access flags for D20AC WESMAINT II+ display screens (Application number: 32045)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 26: Read access flags for D20AC WESMAINT II+ display screens (Application number: 32045)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	D20 AC Main Menu	Yes	Yes	Yes	Yes
1	Circuit Display Page	Yes	Yes	Yes	Yes
2	Circuit Configuration Page	Yes	Yes	Yes	Yes
3	D20 AC Configuration Page	Yes	Yes	Yes	Yes
4 – 31	Not Used	Yes	Yes	Yes	No

Table 27: Modify access flags for Prologic display (Application number: 36)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 28: Read access flags for Prologic display (Application number: 36)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Connect to Prologic Editor	Yes	Yes	Yes	No
1	Request Control of Port	Yes	Yes	Yes	No
2 - 31	Not Used	Yes	Yes	Yes	No

Table 29: Modify access flags for DNP DPA configuration display (Application number: 32021)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-23	Not Used	Yes	Yes	Yes	No
24	Modify Points / Detail Displays	Yes	Yes	Yes	No
25-31	Not Used	Yes	Yes	Yes	No

Table 30: Read access flags for DNP DPA configuration display (Application number: 32021)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	DNP DPA Display	Yes	Yes	Yes	Yes
1-22	Not Used	Yes	Yes	Yes	No
23	Configuration Pages	Yes	Yes	Yes	Yes
24	Detail Pages	Yes	Yes	Yes	No
25 - 31	Not Used	Yes	Yes	Yes	No

Table 31: Modify access flags for internet statistics display (Application number: 162)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 32: Read access flags for internet statistics display (Application number: 162)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	Yes
2 - 31	Not Used	Yes	Yes	Yes	No

Table 33: Modify access flags for DNP serial data link display (Application number: 32013)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 34: Read Modify access flags for DNP serial data link display (Application number: 32013)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	Yes
2 - 31	Not Used	Yes	Yes	Yes	No

Table 35: Modify access flags for Modbus DCA display (Application number: 59)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 36: Read modify access flags for Modbus DCA display (Application number: 59)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	No
2 - 31	Not Used	Yes	Yes	Yes	No

Table 37: Modify access flags for Modbus DPA display (Application number: 68)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 38: Read access flags for Modbus DPA display (Application number: 68)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	Yes
2 - 31	Not Used	Yes	Yes	Yes	No

Table 39: Modify access flags for file upload interface (Application number: 32071)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 40: Read access flags for file upload interface (Application number: 32071)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	No
2 - 31	Not Used	Yes	Yes	yes	No

Table 41: Modify access flags for SOE Logger (Application number: 27)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0-31	Not Used	Yes	Yes	Yes	No

Table 42: Read modify access flags for SOE Logger (Application number: 27)

Bit Position	Description	Administrator (2)	Engineer (1)	Operator (3)	Observer (0)
0	Any Page	Yes	Yes	Yes	No
2 - 31	Not Used	Yes	Yes	Yes	No

D20MX Processor

Appendix B: Standards & Protection

This Appendix lists the standards with which the D20MX has been tested for compliance.

Compliance standards

Compliance standards are listed for the following categories:

- Emission standards; see Table 43
- Immunity standards; see Table 44
- Safety publications; see Table 45
- Environmental standards; see Table 46

Table 43: Emission standards

Standard Name	Description	Test Specification
EN55011 (CISPR 11)[1]	ISM RF equipment – Electromagnetic disturbance characteristics	Radiated Emissions 30 MHz to 1 GHz Conducted Emissions 150 kHz – 30 MHz

Table 44: Immunity standards

Standard Name	Description	Test Specification
IEC 61000-4-2	Electrostatic discharge (ESD) immunity test	Contact Discharge: 8 kV Air Discharge: 15 kV HCP and VCP: 8 kV
IEC 61000-4-3 IEC 61850-3: clause 5.7.2	Radiated, radio-frequency electromagnetic field immunity test	80 MHz to 1 GHz: 10V/m 1.4 GHz to 2 GHz: 3V/m 2 GHz to 3 GHz: 1V/m
IEC 61000-4-4 IEC 61850-3: clause 5.7.1.4	Electrical fast transient/burst immunity test	Direct Couple: 4 kV/5 kHz Capacitive Clamp: 2 kV/ 5 kHz
IEC 61000-4-5	Surge immunity test	

Standard Name	Description	Test Specification
IEC 61000-4-6 IEC 60255-22-6 IEC 61850-3: clause 5.7.1.1	Immunity to conducted disturbances, induced by radio-frequency fields	150 kHz to 80 MHz: 10Vrms
IEC 60255-22-1	1 MHz burst immunity test	
IEC 61000-4-8	Power frequency magnetic field immunity test	
IEC 61000-4-9	Pulse magnetic field immunity test	
IEC 61000-4-12	Ring wave	
IEC 61000-4-11	Voltage dips, short interruptions and voltage variations immunity tests	
IEC 61000-4-16 IEC 61850-3: clause 5.7.1.3	Test for immunity to conducted, common mode disturbances in the frequency range 0 Hz to 150 kHz	30Vrms, 300Vrms
IEC 61000-4-17	Ripple on DC input power port immunity test	
IEC 61000-4-29+	Voltage dips, short interruptions and voltage variations on DC input power port immunity test This standard only applies when using high voltage DC as the source (100 V DC to300 V DC).	

Table 45: Safety publications

Standard Name	Description	Test Specification
IEC 61010-1	Safety requirements for electrical equipment for measurement, control and laboratory use - General requirements	
IEC 60255-5	Insulation coordination for measuring relays and protection equipment-Requirements and tests	Dielectric and Resistance measurements not applicable due to design (TVS in circuit)

Table 46: Environmental standards

Standard Name	Description	Test Specification
IEC 60068-2-1	Cold	144 hours powered at - 20 °C
IEC 60068-2-2[2]	Dry Heat	144 hours powered at + 70 °C
IEC 60068-2-6	Vibration (sinusoidal)	A logarithmic sweep from 10 Hz to 150 Hz to 10 Hz at 1 oct/min for 1 sweep cycle in the 3 orthogonal axes. Acceleration level 1 g
IEC 600255-21-2	Shock - Operating Response Test Shock - Non-Operating Withstand Test	Pulse shape: Half sine Pulse duration: 11 mS - Operating Response Test: Acceleration level: 5 g's - Non-Operating Withstand Test: Acceleration level: 15 g's 3 pulses per polarity per axis for a total of 18 pulses
IEC 600255-21-2	Bump – Non operating test	Pulse shape: Half sine Pulse duration: 16 mS Acceleration level: 10 g's 1000 pulses per polarity per axis for a total of 6000 pulses
IEC 60068-2-30	Damp heat, cyclic (12 h + 12 h cycle)	

Standard Name	Description	Test Specification
IEC 60068-2-31	Drop and topple	Dropping on each face Dropping on each corner Toppling (or pushover) For a total of 12 drops
IEC 60068-2-78	Humidity Testing	96 hours steady state humidity at 40 °C and 93% RH

1 To comply, the D20MX BIOS Spread Spectrum clock setting must be set to “disable”. This is the factory default.
2 To comply, the D20MX BIOS DRAM clock setting must be set to “HCLK-33M”. This is the factory default.

D20MX Processor

Appendix C: List of Acronyms

Acronym Definitions

This Appendix lists and defines the acronyms used in this manual.

Table 47: Acronym list

Acronym	Definition
A	Amperes, unit of measure
AEL	Accessible Emission Limit
ANSI	American National Standards Institute
AWG	American Wire Gauge, unit of measure
bps	bits per second, unit of measure
CCU	Central Control Unit
CE Mark	Mandatory conformity mark for products placed on the market in the European Economic Area (EEA)
CISPR	Special international committee on radio interference
COM1/COM2	Communications port
CPU	Central Processing Unit
CTS	Clear To Send
dBm	decibel-milliwatt, unit of measure - an electrical power unit in decibel (dB)
DCA	Data Collection Application
DCD	Data Carrier Detect
DNP	Distributed Network Protocol
DPA	Data Processing Application
DTE	Data Terminal Equipment
EIA	Electronic Industries Alliance
EMC	Electromagnetic Capability
EMI	Electromagnetic Interference
EPUP	Environmental Protection Use Period
ESD	ElectroStatic Discharge

Acronym	Definition
EU	European Union
FEFI	Far End Fault
FPGA	Field-Programmable Gate Array
GE	General Electric
GOF	glass optical fiber
HCS	Hard Clad Silica
HDLC	High-level Data Link Control
HMI	Human Machine Interface (also called Graphical User Interface – GUI)
Hz	Hertz, unit of measure for frequency
I/O	Input/Output
IEC	International Electrotechnical Commission Standards
IED	Intelligent Electronic Device
ILS	Instrument Landing System
in-lb	inch-pound, unit of measure for energy
IRIG-B	Inter Range Instrumentation Group (IRIG) - an American standardized network time code format
kbps	kilo bits per second, unit of measure
LAN	Local Area Network
lb	pound, unit of measure for weight
LED	Light Emitting Diode
LLA	Loss Link Alert
Mb	Mega bits, unit of measure
MB	Mega bytes, unit of measure
Mbps	Mega bits per second, unit of measure
MBps	Mega bytes per second, unit of measure
MCV	Maximum Concentration Values
MDI	Medium Dependent Interface
MDIX	Medium Dependent Interface, Crossover
ms	milliseconds, unit of measure
Nm	Newton-meter, measure of energy
NTP	Network Time Protocol
NVRAM	Non-Volatile Random Access Memory
PC	Personal Computer
PCBA	Printed Circuit Board Assembly
RMA	Return Merchandise Authorization
RoHS	Restriction of Hazardous Substances
RTS	Request To Send
RTU	Remote Terminal Unit
Rx	Receive
RXD	Receive Data
SCADA	Supervisory Control and Data Acquisition
SNTP	Simple Network Time Protocol
SOE	Sequence Of Events
SQL™	Structured Query Language
TIA	Telecommunication Industries Association
Tx	Transmit
TXD	Transmit Data

Acronym	Definition
UART	Universal Asynchronous Receiver-Transmitter
UTP	Unshielded Twisted Pair
VA	Volt Amps, unit of measure
V AC	Volts, Alternating Current, unit of measure
V DC	Volts, Direct Current, unit of measure
VME	Versa Module Eurocard

D20MX Processor

Index

A

AUTOMATIC ON-LINE STARTUP TEST 55
AUTOMATION APPLICATIONS 16

C

CABLING
- D.20 Link 41
- Ethernet 42
- fiber optic 43
- overview 39
- serial 41

CHASSIS OVERVIEW
- D20 non-VME 18
- D20 VME 19

CODE FILES 56
COMMUNICATIONS SPECIFICATIONS 25
COMPLIANCE STANDARDS AND PROTECTION 91
CONFIGURATION FILES 56
CONFIGURATIONS
- transfer D20/D200 68
- update D20/D200 75

CONNECT THE POWER SUPPLY 37
CUSTOMER SUPPORT 11

D

D.20 LINK CABLING 41
D20
- chassis overview 18
- modems 21
- peripherals 22
- power supplies 20
- system redundancy 47

D20 CHASSIS LAYOUTS 29
D20 NON-VME CHASSIS OVERVIEW 18
D20 VME CHASSIS OVERVIEW 19
D20MX
- connect the power supply 37
- grounding 36
- installation steps 31
- removal steps 83
- retrofit 33
- unpacking 36

D20MX PROCESSOR 15
DEFAULT USER 60
DESIGN OF PRODUCT 15
DOCUMENTATION
- additional 7
- audience 7
- conventions 8

DOWNLOAD
- software over network 64
- software over serial 62
- when 61

E

ECCN NUMBER 15
ELECTRIC SPECIFICATIONS 25
ENVIRONMENT SPECIFICATIONS 26
ETHERNET
- cabling 42
- fiber optic 43
- twisted-pair 42

F

FAIL-OVER CHECK 57
FIBER OPTIC
- cabling 43
- port LEDs 82

FILES

code 56
configuration 56
FIRMWARE
upgrade 12
versions 65
FIRMWARE
options 66
FIRMWARE/FPGA VERSIONS 17
FRONT PANEL LEDS 81

G

GROUNDING D20MX 36

I

IMAGE DOWNLOAD PREREQUISITES 61
INSTALLATION STEPS 31
INTRODUCTION TO SOFTWARE 59
IP ADDRESSES 44

K

KITS 24

L

LAN PORT LEDS 82
LAN REDUNDANCY 44
LEDS
fiber optic port status 82
front panel 81
LAN port status 82
operational status 81
LOCAL USER ACCOUNTS 59

M

MANUAL - HOW TO USE 8
MATERIALS - REQUIRED 35
MODEMS 21

N

NUMBER - ECCN 15

O

OPERATIONAL LEDS 81
OVERVIEW
cabling 39
D20 chassis 18
D20MX processor 15
product 15

P

PACKAGE CONTENTS 36
PERIODIC INSPECTION 83
PERIPHERALS 22
PHYSICAL SPECIFICATIONS 26
PORT - RS-232 47
POWER SUPPLIES 20
POWER-UP 55
POWER-UP AND TEST REQUIREMENTS 53
POWER-UP AND TEST STEPS 54
PRECAUTIONS
safety 13
warning symbols 14
PREREQUISITES FOR IMAGE DOWNLOAD 61
PRODUCT
overview 15
return 12
specifications 25
PRODUCT DESIGN 15

R

RECOMMENDATIONS
storage 27
storage conditions 27
REDUNDANCY
LAN 44
system 47
system - test 56
REGULATORY COMPLIANCE 14
CE mark 14
REMOTE USER ACCOUNTS 59
REMOVAL - D20MX 83
REQUIRED
materials 35
tools 35
REQUIREMENTS - TESTING 53
RETROFIT D20MX 33
RETURN PRODUCT 12
RS-232 PORT 47

S

SAFETY PRECAUTIONS 13
SECURITY 16
SERIAL CABLING 41
SHELL 54
SOFTWARE
download over network 64
download over serial 62
introduction 59
specifications 26
Tera Term set up 62
when to download 61
SOFTWARE APPLICATIONS 16

SOFTWARE PREREQUISITES 61
SPECIFICATIONS
communications 25
electric 25
environment 26
physical 26
product 25
software 26
system 25
STANDARDS AND PROTECTION COMPLIANCE 91
STORAGE
conditions 27
recommendations 27
SUPPORT
customer 11
technical 11
SWITCH-OVER
check 57
verify hardware or software 58
SYSTEM
redundancy 47
specifications 25

T

TECHNICAL SUPPORT 11
TERA TERM SET UP 62
TERMINAL
emulation 54
WESMAINT II+ 54, 55
TERMINAL EMULATOR 62
TEST
automatic on-line startup 55
fail-over 57
requirements 53
switch-over 57
system redundancy 56
TOOLS - REQUIRED 35
TRANSFER D20/D200 CONFIGURATIONS 68
TWISTED-PAIR 42

U

UNPACKING THE D20MX 36
UPDATE D20/D200 CONFIGURATIONS 75
UPDATE FIRMWARE OPTIONS 66
UPGRADE FIRMWARE 12
UPGRADE KITS 24
USER ACCOUNTS
local 59
remote 59

V

VERSIONS
firmware 17
FPGA 17
VERSIONS OF FIRMWARE 65

W

WARNING SYMBOLS 14
WESMAINT II+ 54, 55

Modification Record

Version	Revision	Date	Author	Change Description
1.00	0	October 17, 2012	R. Rees	Original release of this document.
	1	November 6, 2012	R. Rees	Updated D20 applications table and added Firmware/FPGA versions table.
	2	November 23, 2012	R. Rees	Added sections for: Update to the SAN0001 firmware option, Transfer D20/D200 configurations to the D20MX, and Updating D20/D200 Configurations to use the D20MX firmware definition with ConfigPro. Added an Appendix for Resetting a read/write user password.